

**CENTRALINE NX  
BACNET UTILITIES DRIVER**

User Guide





---

# CENTRALINE NX BACNET UTILITIES DRIVER

## 4.4.xx

---

### USER GUIDE

**Software License Advisory**

This document supports software that is proprietary to Honeywell GmbH, Honeywell Control Systems Ltd. and/or to third party software vendors. Before software delivery, the end user must execute a software license agreement that governs software use. Software license agreement provisions include limiting use of the software to equipment furnished, limiting copying, preserving confidentiality, and prohibiting transfer to a third party. Disclosure, use, or reproduction beyond that permitted in the license agreement is prohibited.

**Trademark Information**

CentraLine and 'close to you' are trademarks of Honeywell Inc.

BACnet and ASHRAE are registered trademarks of American Society of Heating, Refrigerating and Air-Conditioning Engineers. Microsoft and Windows are registered trademarks, and Windows Internet Explorer are trademarks of Microsoft Corporation. Java and other Java-based names are trademarks of Sun Microsystems Inc. and refer to Sun's family of Java-branded technologies. Mozilla and Firefox are trademarks of the Mozilla Foundation. Echelon, LON, LonMark, LonTalk, and LonWorks are registered trademarks of Echelon Corporation.

Tridium, JACE, Niagara Framework, NiagaraNX Framework, Sedona Framework and Vykon are registered trademarks, and Workbench, WorkPlaceNX, and NXSupervisor, are trademarks of Tridium Inc. All other product names and services mentioned in this publication that is known to be trademarks, registered trademarks, or service marks are the property of their respective owners.



# CONTENTS

<b>SYSTEM REQUIERMENTS</b>	.....	<b>7</b>
<b>INSTALLATION</b>	.....	<b>7</b>
<b>START CENTRALINE NX</b>	.....	<b>7</b>
Alternate Usage of Different CentraLine NX Versions on Same PC.....		8
<b>OPEN PLATFORM</b>	.....	<b>9</b>
<b>STATION MIGRATION</b>	.....	<b>11</b>
<b>CREATE STATION</b>	.....	<b>16</b>
<b>START AND CONNECT TO STATION</b>	.....	<b>20</b>
<b>CREATE BACNET NETWORK</b>	.....	<b>22</b>
Enable Honeywell BACnet Service .....		25
<b>ADD CONTROLLER TO STATION</b>	.....	<b>27</b>
<b>ADD CONTROLLER OBJECTS TO THE STATION</b> .....		<b>29</b>
Discover Objects of Controller and Add them to Station .....		31
Add Objects to Station via EDE File Import .....		35
<b>VIEW / EDIT DATAPPOINT PROPERTIES</b> .....		<b>40</b>
Datapoint Views .....		40
Procedures .....		42
General Procedure .....		43
View / Edit General Properties.....		44
View Status Flags .....		44
Change Present Value.....		45
Alarming Procedures .....		46
Set Off-Normal Conditions .....		46
Enable / Disable Intrinsic Reporting.....		47
View Command Priorities / Change Relinquish Default.....		48
Set Datapoint Value.....		49
Set Operating Mode - Change Present Value .....		50
Setting Datapoint into Manual Mode (Manual Override).....		50
Setting Datapoint from Override Mode into Auto Mode .....		51
Setting Datapoint into Manual Mode with highest Priority (Emergency Override) .....		52
Setting Datapoint from Emergency Override into Emergency Auto Mode .....		53
View / Change Particular Datapoint Properties.....		53
View / Reset Counters .....		54
Summary .....		55
Detailed Descriptions .....		56
"General" .....		56
Controller .....		56
Status.....		57
Name .....		57
Type.....		57
Description.....		57
Present Value .....		57
Status Flags.....		58
Fault.....		58
In Alarm .....		58
Out Of Service .....		58
Overridden .....		59
Alarming .....		60
High Limit Enable.....		60
Low Limit Enable.....		60
State Text .....		61
Deadband .....		61
Alarm Value .....		62
Suppress Alarm .....		62
Alarm Delay .....		62

Notification Class.....	62
Notify Type.....	62
Reporting Events.....	63
Ackn. Events.....	63
Last Transition.....	63
Other Properties.....	64
Object Identifier.....	64
Reliability.....	65
Event State.....	65
Terminal PV.....	66
Out Of Service.....	66
COV Increment.....	66
Currently Active Priority.....	67
EOV / EOY Optimization.....	67
Datapoint is Setpoint.....	67
Polarity.....	68
Resolution.....	68
Safety Position.....	68
Direct/Reverse.....	69
Safety Value.....	69
Sensor Offset.....	69
Read Access Level.....	70
Write Access Level.....	70
Command Priorities.....	70
Relinquish Default.....	70
Counters.....	71
Change of State Count.....	71
Time of State Count Reset.....	71
Runtime (Active Time).....	71
Time of Last Reset.....	72

**SCHEDULES AND CALENDARS**

.....	<b>73</b>
Schedules.....	73
Edit Weekly Program.....	74
Create Switchpoint.....	74
Change Switchpoint.....	75
Copy Day.....	76
Clear Day.....	77
Clear Week.....	77
Delete Event.....	77
Set Switch Block as All Day Event.....	78
Apply Switch Block to Workdays (Monday through Friday).....	78
Create Special Events.....	79
Set Schedule Properties.....	82
View Schedule Summary.....	84
Calendar References.....	85

**ALARMS**

.....	<b>86</b>
Import / Discover BACnet Notification Classes.....	86
Connect Niagara Alarm Classes to Alarm Console Recipient.....	86
Assign Niagara Alarm Classes to BACnet Notification Classes.....	88
Assign Alarm Extension to Datapoint.....	90
View Alarms.....	91

**TRENDING**

.....	<b>92</b>
-------	-----------

**RESET CONTROLLER CONFIGURATION**

.....	<b>94</b>
-------	-----------

**IRM CONTROLLER PARAMETERS**

.....	<b>94</b>
Load Parameters.....	94
Change Parameters.....	97
Binding of Parameters.....	98

**WEBSTART BROWSER USAGE**

.....	<b>99</b>
-------	-----------

**“HOW TO” INSTRUCTIONS**

.....	<b>99</b>
-------	-----------

**INDEX**

.....	<b>100</b>
-------	------------

## SYSTEM REQUIERMENTS


<b>Niagara</b>	Niagara 4.4.xx and higher.
<b>Products and OS Numbers</b>	For detailed information on the applicable controllers including their OS Numbers, and licenses, please download the corresponding, product data, software release bulletin and/or the compatibility matrix available at:  <b>Product Data</b> <a href="http://products.centraline.com/en/">http://products.centraline.com/en/</a>  <b>Software Release Bulletin</b> <a href="https://www.centraline.com/partnerweb/index.php?id=847&amp;route=article%2Findex&amp;directory_id=47&amp;direct_link=1">https://www.centraline.com/partnerweb/index.php?id=847&amp;route=article%2Findex&amp;directory_id=47&amp;direct_link=1</a>  <b>Compatibility Matrix</b> <a href="https://clfaq.ge51.honeywell.de/?action=artikel&amp;cat=70&amp;id=1616&amp;artlang=en">https://clfaq.ge51.honeywell.de/?action=artikel&amp;cat=70&amp;id=1616&amp;artlang=en</a>
<b>Licenses and Point Handling</b>	When having a license allowing only a limited number of points and you are deleting points, the free number points are not available instantly. To make the free number of points available again, please restart the station.

## INSTALLATION

- Procedure**
1. Unzip the CentraLine NX software to the desired location on your hard disk.
  2. Expand the CentraLine NX installation folder.
  3. Right-click *setup.exe* file for a Win 32-Bit operation system or the *setup\_x64.exe* file for a Win 64-Bit operating system, and then click **Run as Administrator** in the context menu.  
  
 RESULT: The CentraLine NX *Installation Wizard* starts.
  4. Click **Next >** and follow the installation instructions.  
  
 RESULT: After the installation is finished, the CentraLine NX software has been installed according to your selected settings during the setup.


## START CENTRALINE NX

- Procedure**
1. In the Windows *Start* menu, right-click on **COACH NX**, and then click **Run as administrator** in the context menu, or simply click on **COACH NX**.



2. Click **Yes** in the *User Account Control* dialog box.

RESULT: The CentralLine NX main window displays.




---

## Alternate Usage of Different CentralLine NX Versions on Same PC

---

If you have different CentralLine AX and/or NX versions installed on your PC and you want to use them alternately, each time before you start the CentralLine NX software, you must install its dedicated platform daemon. This is necessary in order to make sure that all necessary services are properly running when using the software.

---

## Alternate Usage of Different ARENA NX / COACH NX Versions on Same PC


---

If you have different ARENA NX / COACH NX versions installed on your PC and you want to use them alternately, each time before you start the ARENA NX / COACH NX software, you must install its dedicated platform daemon. This is necessary in order to make sure that all necessary services are properly running when using the software.

**NOTE:** For ARENA NX / COACH NX 4.4.xx which will be installed via setup, the dedicated platform daemon is automatically installed and the corresponding services are running, as long as you do not start another ARENA NX / COACH NX version.


**Example:** You worked with ARENA NX / COACH NX 4.4.76 and you want to use the previous COACH NX 4.3.58 version. Prior to software start, click the **Install Platform Daemon** entry in the *CentralLine* COACH NX 4.3.58 program group.






## OPEN PLATFORM

- Procedure**
1. In the *Nav* side bar, right-click on **My Host** and then click **Open Platform** in the context menu.




RESULT: The *Connect* dialog box displays.




2. In **Type**, select the secure **Platform SSL Connection**, and then click **OK**.

RESULT: If the following message box is displayed, confirm by clicking **Accept**.



RESULT: If the *Authentication* dialog box is displayed.




3. In **Username**, enter your Windows account name.
4. In **Password**, enter your Windows account password.

**IMPORTANT!**

*To connect successfully, you must have admin rights as Windows user.*

5. Click **OK**.

RESULT: You will be connected to the platform and the utilities of the platform are displayed on the *Platform* pane on the right.




## STATION MIGRATION

For the re-use of stations created with ARENA AX / COACH AX versions 3.8.111, it is strongly recommend to migrate the stations using the CI Station Upgrade Tool as described in the following.


**NOTE:** The CI Station Upgrade Tool is specifically designed for the user-friendly migration of CentralLine stations. During this process, some Niagara procedures are executed in the background which are described in detail in the AX to NX Migration User Guide, EN2Z-1025GE51. These procedures can be applied by advanced users if separate manual migration is desired.

It is strongly recommended **not** to apply both migration methods in parallel.



- Procedure**      1. In the **Tools** menu, click on **CI Station Upgrade Tool**.






**RESULT:** The *CI Station Upgrade Tool* wizard is invoked.




2. In the subsequent dialog boxes, select the desired options and confirm each action by clicking the **Next** button.





3. Click **Finish** to complete the migration and exit the CI Station Upgrade Tool.



4. In order to allow running the station, start the **Station Copier** function and copy the station to the "localhost" location.

**NOTE:** During migration, the CL Station Upgrade Tool assigns the default passphrase **Centraline** (case-sensitive) if sensitive data is included in the migrated station. If a station has no sensitive data included, no passphrase will be assigned.


Sensitive data are, for example, client passwords stored in *.BOG* files and station databases (*CONFIG.BOG* files) or station backup distribution (*.DIST*) files. The following areas of the framework can be affected by passphrase implementation:


- Provisioning
- Distribution File Installer
- File Transfer Client
- Station Copier
- Back up
- Commissioning
- Export Tags

For such a migrated station with sensitive data included, the default passphrase is requested and must be entered when initiating the start of the station by copying it to the "localhost" location.

**IMPORTANT!**

*It is strongly recommended to change the default passphrase to a secure one after the migration has been finished.*






- The migration is logged in a report (.HTML file) which can be found at `C:\Users\e671782\Niagara4.3\tridium\stations`. The report shows, for example, which components were deleted.


Name	Date modified	Type	Size
ARENA_AX_Airport	27.03.2017 17:22	File folder	
CBUS_Demo	16.01.2017 17:30	File folder	
CBUS_TEST	18.01.2017 12:01	File folder	
HAWK8000	15.03.2017 12:02	File folder	
Hotel	15.03.2017 10:11	File folder	
IRM	09.03.2017 17:14	File folder	
MERLIN	09.03.2017 17:16	File folder	
Panelbus_controller	27.03.2017 11:41	File folder	
Panelbus_Demo	23.03.2017 17:19	File folder	
Panelbus_Test	23.03.2017 15:21	File folder	
School	07.03.2017 15:14	File folder	
ARENA_AX_Airport_miglog_170327_1722.html	27.03.2017 17:22	HTML Document	16 KB
ARENA_AX_Dominus_Airport_miglog_170327_1133.html	27.03.2017 11:33	HTML Document	16 KB
Panelbus_controller_miglog_170327_1141.html	27.03.2017 11:41	HTML Document	3 KB

## CREATE STATION

- Procedure** 1. From the **Tools** menu, select **New Station**.




RESULT: The *New Station Wizard* displays.






- In **Station Name**, enter a name, and under **Station Templates**, select the required template.




- Click **Next** button.



- In **Password for admin User** and in **Confirm Password for admin User**, enter the administrator password.
- Under **When 'Finish' is pressed, save the station and**, check any of the following options:
  - open it in user home  
creates the station in the *user home* folder


- copy it to secure platform for "localhost" with Station Copier copies the station using the station copier function to the *localhost* folder (recommended)
- close the wizard creates the station and closes the station wizard.




The following screens show the creation of the station by using the recommended option **copy it to secure platform for "localhost" with Station Copier**.

6. Click **Finish** button.



RESULT: The *Loading Module Information* message box displays.



RESULT: Then the *Transferring station ...* dialog box displays.




7. Check whether you want to start the station after copy immediately and once, or whether you want to start the station immediately after copy and automatically every time after platform daemon start.



8. Click **Finish** button.

RESULT: In this example, when the station copier function was used, the copy (transfer) process is successfully completed indicated by the corresponding messages.




9. Click **Close** button.

RESULT: The station will be started.


## START AND CONNECT TO STATION

**Procedure** 1. On the *Platform* pane on the right, double-click on the **Application Director** utility.


RESULT: On the right pane, under *Connected to local host*, all stations are displayed.




2. In the list, select the station, and then click **Start** button on the right.




RESULT: The station is started as indicated by the status 'Running' in the **Status** column.



- In the Nav side bar, right-click on the *My Host* folder, and then click **Open Station** in the context menu.




RESULT: The *Connect* dialog box displays.



- Click **OK**.

RESULT: The *Authentication* dialog box displays.



- If not already done, enter **Username** and **Password** and check **Remember these credentials**.

NOTE: For customer sites it is not recommended to enable the **Remember these credentials** option.

- Click **OK**.

RESULT: The station will be opened. On the *Station* pane on the right the components of the station are displayed:

- Alarm
- Config
- Files
- Spy
- Hierarchy
- History

At the bottom, the *Summary* pane displays general properties and its settings (Station Name, Host, etc.) of the station.

The screenshot shows the Honeywell BACnet Utilities Driver interface. The main content area displays a table of station components:

Name	Description
Alarm	Alarm Database
Config	The station configuration database
Files	File System accessed over Fox session
Spy	Diagnostics information for remote VM
Hierarchy	Hierarchy views of remote station
History	History database

Below the table is the **Summary Properties** pane, which displays the following information:

Property	Value
Station Name	School
Host	GE51DTF857G32.global.ds.honeywell.com/160.221.67.191
Host Model	Workstation
Product	Workstation
Host Id	Win-27A4-CEDA-8968-4C3E
Niagara Version	4.2.36.34
Java Version	Java HotSpot(TM) 64-Bit Server VM 25.92-b14
OS Version	amd64 Windows 7 6.1
Locale	en_US
Current Time	31-Jan-17 1:55 PM CET

## CREATE BACNET NETWORK

### Choose Working Environment - Work with or without BACnet Utilities


Before creating a BACnet network, you can choose the working environment by using the Centraline Add-ons (views, and reading, changing and saving of time programs) provided by the BACnet Utilities driver or by either working without these driver features.

The Centraline Add-ons are only applicable if the Honeywell BACnet service (HonBACnetService) is enabled. If the Centraline Add-ons are not desired, this service should not be enabled.

If you want to use the Centraline Add-ons, please enable the Honeywell BACnet Service as described in the subsequent "Enable Honeywell BACnet Service" section before you create the BACnet network.


If you do not want to use the Centraline Add-ons, please continue with the procedure described below.

- Procedure**
1. In the *Nav* side bar, expand the *Station* folder, and then click on **Drivers**.




2. On the right pane, click **New**.

RESULT: The *New* dialog box displays.




3. In **Type to Add**, select the BACnet network type, e.g. 'Bacnet Ows Network'.




4. Click **OK**.

RESULT: The *New* dialog box is updated.



5. Click **OK**.

RESULT: The BACnet network is created and its properties are displayed on the *All Bacnet Network Properties* tab.




6. In **Object Id**, change the default Id = -1 by entering another but unique ID.

7. In **Adapter**, select the network adapter which is connected to the BACnet bus.

8. In **IP Port Enabled**, select 'true'.


9. If you have a mixed configuration with EAGLE and FALCON controllers, select the 'ISO5889-1' character set in **Character Set**, otherwise leave the default setting.




10. Click **Save** at the bottom.



RESULT: If all properties are selected appropriate and if the hardware is properly installed, the **Ip Port Status** field is set to 'true'.



The network is added to the *Drivers* folder in the *Nav side bar*.



## Enable Honeywell BACnet Service

The Honeywell BACnet service must be enabled if you want to use the CentralLine specific Add-ons provided by the CentralLine BACnet Utilities driver. This step must be done before creating the BACnet network.

Enabling the service includes 2 steps:


1. Adding the service to the *Services* tree
2. Enabling the service on its *Properties Sheet*

In CentralLine NX 4.2.xx.xx.x.x and lower, the service is already added to the *Services* tree by default. In CentralLine NX 4.3.xx.xx.x.x and higher, the service is not available by default and must be added to the *Services* tree manually.


NOTE: When using a station from a previous project in CentralLine NX 4.4.xx.xx.x.x, the Honeywell BACnet Service is available in disabled state as shown in the *Services* tree and on the *Properties Sheet*. If available, the

Honeywell BACnet Service can be enabled/disabled at any time on the *Properties Sheet*

- Procedure**
1. In the *Palette* tab at the bottom, select **honBACnetUtilities** from the drop-down listbox, then open *Services*, and then drag&drop the **HonBACnetService** item to the *Services* folder.




RESULT: The *Name* dialog box displays.




2. Change the name if desired, and then click **OK**.


RESULT: The service is added to the *Services* folder.



3. Double-click the **HonBacnetService** in the tree.




- On the *Property Sheet* on the right, select 'true` in the **Enabled** drop-down listbox.



- Click the **Save** button at the bottom.

RESULT: The service will be started indicated by 'true` setting in the **Running** drop-down listbox.




- Continue by creating the BACnet network as described in the previous "Create BACnet Network" section.

## ADD CONTROLLER TO STATION


### Procedure

- In the *Nav* side bar, expand the *Station* folder, and then click on the BACnet network on which you want to discover BACnet devices.




- On the right *Database* pane, click **Discover**.

RESULT: The *Configure Device Discovery* dialog box displays.




3. Click **OK**.

RESULT: In the upper *Discovered* area, the found BACnet devices are displayed.



4. Select the device, and then click the **Add** in the buttons bar at the bottom.

RESULT: The *Add* dialog box displays.




5. In Type, select the device type, for EAGLE, FALCON, or HAWK, select CI, for all others, and select "Standard" BACnet Device.

6. Click **OK**.


RESULT: The device is added to the database as indicated in the *Database* area.

In the *Nav side bar*, the device is added to the station and displayed under the BACnet network.



7. To show, load or save device properties, double-click the device.

RESULT: On the right pane, the device properties are displayed. You can load properties from the device by clicking the **Refresh** button, or you can edit properties and write them to the device by clicking the **Save** button.



8. To add controller objects to the station such as datapoints, schedules etc. you can use the items below the controller icon in the *Nav side bar* (see "Add Controller Objects to the Station" section)

## ADD CONTROLLER OBJECTS TO THE STATION

The controller includes the following objects that can be added to the station:

- datapoints
- schedules
- calendars

- notification classes
- trends (online mode only)

ARENA NX / COACH NX provides two ways to add these objects to the station:

- **Objects Discovery in Online Mode**

Objects will be discovered in the connected controller and added manually to default or user-definable folders in the *Nav side bar* (see "Discover Objects of Controller and Add them to Station" section)

- **EDE File Import in Offline and Online Mode**

An *.EDE* file containing the objects with their original CARE project tree structure will be imported and displayed in ARENA NX / COACH NX (see "Add Objects to Station via EDE File Import" section).

The EDE file will be automatically created when translating the controller in CARE. It can be found in the corresponding project folder of the CARE directory. A further *.StateTexts* file containing the state texts must be imported too.

#### **EDE File Import and Controller Creation**

The *.EDE* file import slightly differs dependent on how the applied controller had been created, manually or via discovery and addition. When a controller is created manually, the device ID = -1 is assigned to the controller by default. After import of the *.EDE* file, the default device ID (= -1) will be automatically replaced with the device ID of the controller in the CARE project. But, the network address and MAC address must be entered manually in accordance with the controller data. When a controller is created via Discovery and Add command, the device ID in the *.EDE* file and in the created controller are validated. For a successful import, they should be identical. If they are not identical, an error message will be displayed. The network address and MAC address need not be entered manually.

NOTE: The offline import function is supported by CARE 10.04.00 or higher and by previous CARE versions that are updated with the *CtrlAppGen.dll*. The *.dll* file will be provided on the Centraline Partner Web (see ARENA NX Software Release Bulletin for details).




Fig. 1. Objects Discovery and EDE-File Import in Online and Offline Mode

Prior to the execution of the discovery or import function, the controller in the *Nav side bar* already shows the following empty default folders:

- Alarm source info
- Points
- Virtual
- Alarms
- Schedules
- Trend Logs
- Config


When applying the discovery method, you can add the discovered objects to the corresponding default folders, e.g. datapoints to the *Points* folder, or you can add the discovered objects to folders created by your own.

When applying the import EDE file method, the default folders will be overridden by the imported CARE folders.


## Discover Objects of Controller and Add them to Station

**Purpose** In the following, the discovery of all objects in the connected controller and, as an example, the addition of datapoints to the station is described. This procedure is done online with the connected controller and does not import the tree structure of the CARE project. Hence, you can individually create folders and arrange the discovered objects in the folders. All objects of the controller can be added to the station.


- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the controller.



2. Double-click the folder which you want to add datapoints to, e.g. the *Points* folder, if you want to discover and add datapoints



3. At the top on the right pane, select the **Hon Bacnet Point Manager** view which provides a filter function for datapoints.



4. Click the **Discover** button.

**RESULT:** All objects of the controller will be listed in the upper *Discovered* pane.



Bacnet Discover Points Success >> [X]

Discovered 223 objects

Object Name	Object ID	Property ID	Index	Value	Description
Fac01_temp_sp0	analogValue:33	presentValue		23.00	
Fac01_temp_sp_LR	analogValue:36	presentValue		23.00	
Fac01_temp_sp1	analogValue:278	presentValue		21.00	
Fac01_temp_sp2	analogValue:279	presentValue		21.00	
Fac01_temp_sp3	analogValue:280	presentValue		21.00	
Fac01_temp_sp4	analogValue:281	presentValue		21.00	

Database 0 objects

Name	Out	Object ID	Property ID	Index	Read	Write
------	-----	-----------	-------------	-------	------	-------


5. Select the datapoints you want to add to the station. Multi-selection using the SHIFT or STRG key is possible.

Discovered

Object Name	Object ID	Property ID	Index	Value	Description
5HI75712IC1_OFF_DELAY	analogValue:235	presentValue		30.00	Tid for efterløb pir
5HI75712PI2	analogInput:189	presentValue		0.00	Tryktransmitter indblæsning OP-stue HA706
5HI75712PI2_L	binaryValue:195	presentValue		Inactive	Indikering af lampe ventilations drift
5HI75712PI2_VEN	analogValue:233	presentValue		450.00	Setpoint tryk indblæsning
5HI75712SM2	analogOutput:184	presentValue		0.00	Spjæld kold kanal
5HI75712SM4	analogOutput:185	presentValue		100.00	Spjæld varm kanal
5HI75712TC1	analogInput:188	presentValue		8.90	Indblæsningstemperatur OP-stue HK706
5HI75712TC1SK	analogValue:231	presentValue		22.00	Kalkulerat setpunkt
5HI75712TC1_max	analogValue:229	presentValue		22.00	Maximum setpunkt
5HI75712TC1_min	analogValue:230	presentValue		16.00	Minimum setpunkt
5HI75712_INTER_HYS	analogValue:234	presentValue		2.00	Hysteres intermittent drift
AHU01_AV21_Seat02	analogValue:21	presentValue		0.00	
AHU01_AV22_Seat03	analogValue:22	presentValue		0.00	
AHU01_AV23_Seat04	analogValue:23	presentValue		0.00	
AHU01_AV24_Seat05	analogValue:24	presentValue		0.00	


6. Click **Add** button.

RESULT: The *Add* dialog box displays.



7. Click **OK**. Do not modify any settings of the datapoints, these will be reset based on a pre-defined mechanism while adding to the database.

**RESULT:** The selected datapoints are added to the station. They are displayed twice, in the lower *Database* pane and in the *Points* folder in the *Nav side bar*.



8. It is recommended to create a structure for arrangement of the different datapoint types by clicking the **New Folder** button. The use of these folders will help to reduce the load on the BACnet bus while subscribing Cov.

9. After you are finished with the creation of the structure, move the datapoints to the corresponding folders.

## Add Objects to Station via EDE File Import


**Purpose** In the following, the automatic addition of all controller objects to the station is described.

This procedure is done offline without controller connection and imports the objects and the complete tree structure of the CARE project. Hence, you do not need to create folders and arrange the objects in folders manually.


It may occur that some objects cannot be imported to the station due to naming convention mismatches between ARENA NX / COACH NX and CARE. These objects must be added to the station online and manually using the Discovery function.

**NOTE:** During EDE file import, the device is disabled temporarily and will be enabled after the import is finished.

- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the controller.
  2. Right-click the controller, click **Actions** and then click **Import from Ede** in the context menu.




**RESULT:** The *BACnet Objects Importer* wizard displays.




7. Click **Next** button.

**RESULT:** The following *BACnet Objects Importer* wizard displays.



- 3. Check the **Import...** options that state the objects to be imported (data points, notification classes, schedules, calendars) and uncheck the options, you do not want to apply.
- 4. In the **Choose EDE file to import from** field, click the **Browse** button.


RESULT: The *File Chooser* dialog box displays.



- 5. Browse to the folder where the EDE file is saved, select it, and then click **Open** button.


NOTE: It is recommended to select the ...utf8 file version since this version supports the most characters, e.g. umlauts.

RESULT: The path of the selected EDE file is displayed in the **Choose EDE file to import from** field.




7. Click **Next** button.

RESULT: The EDE file for the state texts is indicated for import in the **Choose State Texts File to import from** field.




8. Import this EDE file in the same way as the main EDE file described in step 6 et. seq.



9. Click **Next** button.

RESULT: The **Summary** report is shown in the *BACnet Objects Importer* wizard screen. If objects are not imported, please read the message carefully and import the objects manually using the Discovery function.



10. Click **Finish** button.

RESULT: In the *Nav side bar* below the controller, the complete tree structure of the CARE project with all importable objects is displayed. Datapoints and their folders are arranged below the *Points* folder, schedules and calendars are arranged below the *Schedules* folder.

Nav

My Network

- Drivers
  - NiagaraNetwork
  - BacnetOwsNetwork
    - Local Device
    - Bacnet Comm
    - Monitor
    - Tuning Policies
    - EAGLE**
      - Alarm Source Info
      - Points
        - Factory
        - Office Boiler room
        - Office FLOOR 0
        - Office FLOOR 1
        - Office FLOOR 2
        - Office FLOOR 3
        - Office FLOOR 4
        - Office FLOOR 5
        - ReferencePlant
        - Store
        - Touchpanel Room Control
        - Air\_Handling\_Unit
      - Virtual
      - Alarms
      - Schedules
        - Retry Trigger
        - Time Program Setpoint Room T
        - Holiday
        - Company vacations
        - Schedule Factory Building
        - Schedule Office
        - Schedule Store
        - Schedule Factory
        - Schedule Building
        - Schedule Store Building
        - Time Program Plant enable
      - Trend Logs
      - Config

Bacnet Discover Points

Discovered

Object Name	Object ID	Property ID	Index	Value	Description
Fac01_temp_sp0	analogValue:33	presentValue		23.00	
Fac01_temp_sp_LR	analogValue:36	presentValue		23.00	
Fac01_temp_sp1	analogValue:278	presentValue		21.00	
Fac01_temp_sp2	analogValue:279	presentValue		21.00	
Fac01_temp_sp3	analogValue:280	presentValue		21.00	
Fac01_temp_sp4	analogValue:281	presentValue		21.00	
Fac01_temp_LR	analogValue:299	presentValue		0.00	
Fac01_temp0	analogValue:300	presentValue		0.00	
Fac01_temp1	analogValue:301	presentValue		0.00	
Fac01_temp2	analogValue:302	presentValue		0.00	
Fac01_temp3	analogValue:303	presentValue		0.00	
Fac01_temp4	analogValue:304	presentValue		0.00	
Fac01_valve_LR	analogValue:305	presentValue		0.00	
Fac01_valve0	analogValue:306	presentValue		0.00	
Fac01_valve1	analogValue:307	presentValue		0.00	

Database

Name	Out	Object ID	Property ID	Index
Factory	BacnetPointFolder:Factory			
Office Boiler room	BacnetPointFolder:Office\$20Boiler\$20room			
Office FLOOR 0	BacnetPointFolder:Office\$20FLOORS\$200			
Office FLOOR 1	BacnetPointFolder:Office\$20FLOORS\$201			
Office FLOOR 2	BacnetPointFolder:Office\$20FLOORS\$202			
Office FLOOR 3	BacnetPointFolder:Office\$20FLOORS\$203			
Office FLOOR 4	BacnetPointFolder:Office\$20FLOORS\$204			
Office FLOOR 5	BacnetPointFolder:Office\$20FLOORS\$205			
ReferencePlant	BacnetPointFolder:ReferencePlant			
Store	BacnetPointFolder:Store			
Touchpanel Room Control	BacnetPointFolder:Touchpanel\$20Room\$20Control			
Air_Handling_Unit	BacnetPointFolder:Air_Handling_Unit			

---

## VIEW / EDIT DATAPPOINT PROPERTIES

---

The properties of a datapoint vary dependent on the datapoint type. The following datapoint types are available in ARENA NX / COACH NX:

- analog input (AI)
- analog output (AO)
- analog value (AV)
  
- binary input (BI)
- binary output (BO)
- binary value (BV)
  
- multi-state input (MI)
- multi-state output (MO)
- multi-state value (MV)

For detailed descriptions of the properties of a particular datapoint, please refer to the "BACnet Datapoint Properties Descriptions" section.

Viewing/editing datapoint properties may include tasks which can be done the following General areas:

### "General"

- View properties such as description, present value and status flags
- Override present value manually

### Alarming

- Enable/disable alarming
- Enable/disable intrinsic reporting
- Set Off-Normal conditions

### Command Priorities

- View command priorities states
- Change relinquish default value

### Other Properties

- View common properties such as event state, reliability, read and write access level
- View and change particular datapoint dependent properties such as COV increment, sensor offset, safety position, etc.

### Counters

- View and reset state counter and runtime counter.

---

## Datapoint Views


---

In the CentralLine NX workbench different views for datapoint properties are provided. This allows working either in the standard Niagara AX view or in the Honeywell BACnet view. In the following, the Honeywell BACnet views are described. In order to use the Honeywell BACnet views, the 'HonBACnetService' must be enabled before.

Datapoints can be viewed in 2 different modes selectable in the context menu:

- Hon BACnet Point Properties View
- Hon Data Point View





**Hon BACnet Point Properties**

The datapoint properties in the Hon BACnet Point Properties view look as follows:

Controller: EAGLE Status: ● OK

Name:  Type:

Description:

Present Value:  °C  Auto  Manual

Status:  inAlarm  fault  overridden  outOfService

Alarming | **Command Priorities** | Other Properties

**Off-Normal Conditions**

Limit Enable  Low Limit Enable  High Limit Enable

High Limit:  °C

Low Limit:  °C

Dead Band:

Suppress Alarm

Alarm Delay:  s

**Intrinsic Reporting**

Notification Class:

Notify Type:

**Transitions**

Reporting Events  toOffnormal  toFault  toNormal

Ackn. Events  toOffnormal  toFault  toNormal

**Last Transition**

To-Off Normal:

Back-To Normal:

To Fault:

NOTE: The following procedures descriptions are based on this view.

**Hon Data Point View**

Shows the datapoint properties in Web browser design.

The datapoint properties in the Hon Data Point View look as follows:



- View and change particular datapoint dependent properties such as COV increment, sensor offset, safety position, etc.

See "View / Change Particular Datapoint Properties" section

**Counters**

- View and reset state counter and runtime counter


See "View / Reset Counters" section

**General Procedure**


The following procedure gives a short and general overview on how to view and edit the properties of a datapoint.

**Procedure**

1. To view/edit the properties of a datapoint, double-click the datapoint in the *Points* folder of the *Nav side bar*.



**RESULT:** On the right pane, the properties of the datapoint are displayed. On the top, General properties such as name, description, present value etc. and status flags are shown.



Depending on the datapoint type, further properties are arranged on the *Alarming*, *Command Priorities*, *Counters*, and *Other Properties* tabs.

NOTE: Some fields are for display only. Others can be edited. The display of the tabs is dependent on the datapoint type. For some datapoint types, particular tabs are not available.

Alarming

Other Properties

**Off-Normal Conditions**

Limit Enable  Low Limit Enable  High Limit Enable

High Limit  °C

Low Limit  °C

Dead Band

Suppress Alarm

Alarm Delay  s

**Intrinsic Reporting**

Notification Class

Notify Type

**Transitions:**

Reporting Events  toOffnormal  toFault  toNormal  toAlert

Ackn. Events  toOffnormal  toFault  toNormal  toAlert

**Last Transition**

To-Off Normal

Back-To Normal

To Fault

Refresh

Save

2. To change a datapoint property, choose the present value field in the General properties or if necessary, select a tab and choose the desired field there, enter/select the value, and then click the **Save** button Save at the bottom. This writes the value to the controller.

To upload the present value from the controller, click the **Refresh** button Refresh at the bottom. This overwrites **all** values to ARENA NX / COACH NX if these values are different to the values in the controller.

3. Continue by applying any of the particular procedure(s) as described in the following.

---

### View / Edit General Properties

This procedure includes the following:

- View properties such as description, status flags, and present value
- Override present value manually

---

### View Status Flags

NOTE: This procedure applies to all datapoint types.

- Procedure**
1. Display the datapoint properties as described in the "General Procedure" section.

RESULT: On the right pane, the status flag settings are shown under **Status**. Active status flag are checked, inactive status flags are unchecked.

2. If desired, continue by changing the present value as described in the "Change Present Value" section.
3. If desired, continue by viewing / editing particular settings on any of the following tabs:
  - Alarming
  - Command Properties
  - Other Properties

Refer to the corresponding subsequent sections.

### Change Present Value

NOTE: This procedure applies to all datapoint types.

**Procedure**

1. Display the datapoint properties as described in the "General Procedure" section.

RESULT: On the right pane, the properties of the datapoint are displayed.

**Controller**

Shows the name of the controller

**Status**

Shows the status of the controller (OK, Down, Disabled)

**Name**

Shows the name of the datapoint

**Type**

Shows the type of the datapoint

**Description**

Shows a description of the datapoint if entered in CARE (optional)

**Present Value**

Shows the present value. To change the present value, see step. 2.

**Status**

Shows the status flags settings.

2. To change the present value, click the Manual checkbox, enter the value, and then click the **Save** button at the bottom. This writes the value to the controller.

To upload the present value from the controller, click the **Refresh** button at the bottom. This overwrites the currently displayed value if the values are different.

3. If desired, continue by viewing / editing settings on any of the following tabs:
  - Alarming
  - Command Properties
  - Other Properties
  - Chart

Refer to the corresponding subsequent sections.

## Alarming Procedures

These procedures include the following tasks:

- Set Off-Normal conditions
- Enable/disable intrinsic reporting

### Set Off-Normal Conditions

- Procedure** 1. Display the datapoint properties as described in the "General Procedure" section, step 1.

**RESULT:** On the right pane, select the *Alarming* tab.

The screenshot shows the 'Alarming' tab of a software interface. It is divided into two main sections: 'Off-Normal Conditions' and 'Intrinsic Reporting'.  
**Off-Normal Conditions:**  
 - Limit Enable:  (checked)  
 - Low Limit Enable:  (checked)  
 - High Limit Enable:  (checked)  
 - High Limit: 38.00 °C  
 - Low Limit: -25.00 °C  
 - Dead Band: 0.00  
 - Suppress Alarm:  (unchecked)  
 - Alarm Delay: 0 s  
**Intrinsic Reporting:**  
 - Notification Class: LOW (dropdown menu)  
 - Notify Type: Event (dropdown menu)  
**Transitions:**  
 - Reporting Events:  toOffnormal,  toFault,  toNormal,  toAlert  
 - Ackn. Events:  toOffnormal,  toFault,  toNormal,  toAlert  
**Last Transition:**  
 - To-Off Normal: \*\*\*\*-\*\*-\*\*-\*\* \*\*:\*:\*:\*  
 - Back-To Normal: \*\*\*\*-\*\*-\*\*-\*\* \*\*:\*:\*:\*  
 - To Fault: 2015-12-26-Sat\_02:04:58.00

**Alarming tab example "Analog Input"**

2. Under **Off-Normal Conditions** do any of the following.

*All datapoint types:*

#### Suppress Alarm

- Check the **Suppress Alarm** dialog box to disable alarming.
- Or, uncheck the **Suppress Alarm** dialog box to enable alarming.
- Click **Save** button.

#### Alarm Delay

- Enter the alarm delay value in seconds in the **Alarm Delay** field (disabled if suppress Alarm is enabled)
- Click **Save** button.

*AI, AO, and AV datapoint types:*

#### Limit Enable – High Limit – Low Limit

- Check **Low Limit Enable** and enter the value in the **Low Limit** field
- Check **High Limit Enable** and enter the value in the **High Limit** field
- Click **Save** button.


#### Dead Band

- Enter the value of the dead band.
- Click **Save** button.

BI and BV datapoint types:

**Alarm Value**


- From the **Alarm Value** drop-down listbox, select the alarm value setting.
- Click **Save** button.



MI and MV datapoint types:

**State Text – Is Alarm Condition – Is Fault Condition**

Here the states are displayed which represent and set off an 'Alarm' and/or a 'Fault' event.



3. If desired, continue by viewing / editing settings on any of the following tabs:

- Command Properties
- Other Properties
- Chart

Refer to the corresponding subsequent sections.


**Enable / Disable Intrinsic Reporting**

NOTE: This procedure applies to all datapoint types, except the BO datapoint.

**Procedure**

1. Display the datapoint properties as described in the "General Procedure" section, step 1.

RESULT: On the right pane, select the *Alarming* tab.



2. Under **Intrinsic Reporting** do any of the following.

**Notification Class**

Allows selecting the notification class.

**Notify Type**

Displays the notification class and the notify type.

**Transitions**

- Check the transition types you want to be reported from **toOffnormal**, **toFault**, and **ToNormal**. The reported transitions will be saved in the alarm buffer and in the alarm list.
- Click **Save** button.

**Ack. Events**

Each transition is unacknowledged (unchecked) by default.

**Last Transition**

Here the dates (timestamp) of the last transitions are shown in the **To-Off Normal**, **Back-To Normal** and **To Fault** fields.

3. If desired, continue by setting off-normal conditions as described in the "Set Off-Normal Conditions" section.
4. If desired, continue by viewing / editing settings on any of the following tabs:
  - Command Properties
  - Other Properties

Refer to the corresponding subsequent sections.

## View Command Priorities / Change Relinquish Default

NOTE: This procedure applies to AO, AV, BO, BV, MO, and MV datapoint types only.

This procedure includes the following:

- View command priorities states
- Change relinquish default value

- Procedure**
1. Display the datapoint properties for the corresponding datapoint type as described in the "General Procedure" section.

**RESULT:** On the right pane, the properties of the datapoint are displayed. By default, the *Command Priorities* tab is selected. The priority levels with their current values are shown.





2. To change the relinquish default value, do any of the following:
  - a. for binary and multi-state points, select the value in the **Relinquish Default** drop- down listbox.
  - b. for analog points, enter the value in the **Relinquish Default** field.
3. Click the **Save** button.


This function can also be executed by using the Set command for the datapoint as described in the subsequent "Set Datapoint Value" section.

## Set Datapoint Value


NOTE: This procedure applies to all datapoint types, except the AI datapoint type.

**Purpose** Sets the relinquish default value of the datapoint. The relinquish value of a datapoint defines the value that will be written to the present value if the priority array is empty which means that no other value is present in the priority array. The relinquish default value allows starting up a control system with a defined status/value.


- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *Points* folder.
  2. Right-click the datapoint, click **Actions** and then click **Set** in the context menu.



RESULT: The Set dialog box displays.



3. Enter the fallback value.




4. Click OK.

RESULT: The **Fallback** field and the **Out** field are updated with the defined value.


## Set Operating Mode - Change Present Value

NOTE: These procedure applies to the AI datapoint type only.

1. Right-click the analog input datapoint in the *Nav side bar*, then click **Actions**, and then click **Set Operating Mode** in the context menu.



2. In the *Set Operating Mode dialog box*, select the operating mode, and if 'Manu' has been selected, enter the present value.



3. Click **OK**.

4 If desired, continue by viewing / editing settings on any of the following tabs, e.g.:

- Alarming
- Counters
- Other Properties
- Event Enrollments


Refer to the corresponding subsequent sections.

## Setting Datapoint into Manual Mode (Manual Override)


**Purpose** Sets the datapoint into Manual operating mode and overwrites the present value with a defined value entered manually. This command is executed on priority level In8.

NOTE: This procedure applies to all datapoint types, except the AI datapoint type.


- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *Points* folder.
  2. Right-click the datapoint, click **Actions** and then click **Override** in the context menu.



RESULT: The *Override* dialog box displays.



3. In the **Override Value** field, enter the value.




4. From the **Override Duration** drop-down listbox, select the duration.
5. Click the **OK** button.

### Setting Datapoint from Override Mode into Auto Mode

**Purpose** Sets a datapoint that is in override (manual) mode into Automatic mode.

NOTE: This procedure applies to all datapoint types, except the AI datapoint type.

- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *Points* folder.
  2. Right-click the datapoint, click **Actions** and then click **Auto** in the context menu.




### Setting Datapoint into Manual Mode with highest Priority (Emergency Override)


**Purpose** Sets the datapoint into manual operating mode and overwrites the present value with a defined value entered manually. This command is executed on priority level In1.

**NOTE:** This procedure applies to all datapoint types, except the AI datapoint type.


- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *Points* folder.
  2. Right-click the datapoint, click **Actions** and then click **Emergency Override** in the context menu.



**RESULT:** The *Emergency* dialog box displays.



3. Enter the value.



4. Click the **OK** button.


‘overridden’ is displayed. The **Out** field shows the manual value as the current value. The **Operating Mode** field shows the mode ‘Manual’.

## Setting Datapoint from Emergency Override into Emergency Auto Mode

**Purpose** Sets a datapoint that is in emergency override mode into Automatic mode.

NOTE: This procedure applies to all datapoint types, except the AI datapoint type.

- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *Points* folder.
  2. Right-click the datapoint, click **Actions** and then click **Emergency Auto** in the context menu.



## View / Change Particular Datapoint Properties

This procedure includes the following:

- View common properties such as event state, reliability, read and write access level
- Change particular datapoint dependent properties such as COV increment, sensor offset, safety position, etc.

NOTE: Viewing common properties applies to all datapoints. Changing particular datapoint properties is dependent on the datapoint type and does not apply to any datapoint.

- Procedure**
1. Display the datapoint properties for the desired datapoint as described in the "General Procedure" section.
- RESULT: On the right pane, the properties of the datapoint are displayed. For detailed information of the particular properties please refer to the "BACnet Datapoint Properties Descriptions" section.

Alarming	Other Properties
Object Identifier	analogInput:2
Reliability	Open Loop
Terminal PV	Onboard/AI/4
Event State	Fault
COV Increment	0.00
Sensor Offset	0.00 °C
Out of Service	false
Safety Value	<input checked="" type="checkbox"/> Last valid value 0.00 °C
Resolution	0.00

In the following, the change of the COV Increment value is described as an example.

2. In the COV Increment field, enter a new value.

3. Click the **Save** button.
4. If desired, continue by viewing / editing settings on any of the following tabs:
  - Alarming
  - Event Enrollments

Refer to the corresponding subsequent sections.

### View / Reset Counters

NOTE: This procedure applies to BI, BO, and BV datapoint types only. This procedure includes the following:

- View and/or reset state and/ or runtime counters

**Procedure**

1. Display the datapoint properties as described in the "General Procedure" section.

RESULT: On the right pane, the properties of the datapoint are displayed.

2. Select the *Counters* tab.

Under **Change of State Counter**, the number of state changes is displayed. Under **Runtime Counter**, the active runtime is displayed.

3. To reset the state counter to '0', click the **Reset** button right to the **Change of State Count** field.
4. To reset the runtime to '0', click the **Reset** button right to the **Runtime (Active Time)** field.
5. If desired, continue by viewing / editing settings on any of the following tabs:
  - Command Properties
  - Other Properties
  - Event Enrollments

Refer to the corresponding subsequent sections.

Summary

The following table gives an overview of the BACnet properties for all datapoint types:

- AI (analog input)
- AO (analog output)
- AV (analog value)
- BI (binary input)
- BO (binary output)
- BV (binary value)
- MI (multi-state input)
- MO (multi-state output)
- MV (multi-state value)

Datapoint Property	Datapoint Type								
	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>"General"</b>									
Present Value									
auto, manual	x	x	x	x	x	x	x	x	x
Status									
in alarm	x	x	x	x	x	x	x	x	x
fault	x	x	x	x	x	x	x	x	x
overridden	x	x	x	x	x	x	x	x	x
out of service	x	x	x	x	x	x	x	x	x
<b>Alarming</b>									
Off-Normal Conditions									
low limit enable	x	x	x						
high limit enable	x	x	x						
low limit	x	x	x						
high limit	x	x	x						
dead band	x	x	x						
alarm value				x		x			
state text							x		x
suppress alarm	x	x	x	x		x	x		x
alarm delay	x	x	x	x		x	x		x
Intrinsic Reporting									
notification class	x	x	x	x	x	x	x	x	x
notify type	x	x	x	x	x	x	x	x	x
Transitions									
reporting events	x	x	x	x	x	x	x	x	x
ackn. events	x	x	x	x	x	x	x	x	x
Last transition									
to-off normal	x	x	x	x	x	x	x	x	x
back-to normal	x	x	x	x	x	x	x	x	x
to fault	x	x	x	x	x	x	x	x	x
<b>Command Priorities</b>									
relinquish default		x	x		x	x		x	x
<b>Other Properties</b>									
object identifier	x	x	x	x	x	x	x	x	x
reliability	x	x	x	x	x	x	x	x	x
event state	x	x	x	x	x	x	x	x	x
terminal PV	x	x		x	x		x	x	
out of service	x	x	x	x	x	x	x	x	x
COV increment	x	x	x						
currently active priority		x	x		x	x		x	x
EOH / EOv optimization flag			x			x			x

Datapoint Property	Datapoint Type								
	AI	AO	AV	BI	BO	BV	MI	MO	MV
datapoint is setpoint			x			x			x
polarity				x	x				
resolution	x	x							
safety position		x			x				
direct reverse		x							
safety value	x			x					
sensor offset	x								
read access level	x	x	x	x	x	x	x	x	x
write access level	x	x	x	x	x	x	x	x	x
<b>Counters</b>									
Change of State Counter									
change of state count				x	x	x			
time of state count reset				x	x	x			
Runtime Counter									
runtime (active time)				x	x	x			
time of last reset				x	x	x			

## Detailed Descriptions

This section describes all BACnet datapoint properties in detail. Each property description starts with a table that explains:

- which datapoints the property applies to
- if the property is editable

Example: The following table explains the **Alarm Delay** property. In this case the property applies to the BI and BV datapoint types. It can be edited.

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>						X			

The table is followed by the detailed description of the property.

### "General"

"General" properties are the following:

- controller
- status
- name
- type
- description
- present value
- status flags

### Controller

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>									

Shows the name of the controller



**Status**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows the status of the controller

**Name**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows the name of the datapoint.

**Type**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows the type of the datapoint e.g. analog input.

**Description**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows an optional description of the datapoint entered in CARE.

**Present Value**

**Auto**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Sets the datapoint in automatic (Auto) operation mode. In Auto operation mode, the datapoint shows the present value processed by the controller (sensor input values, time program output values).

**Manual**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	x								

Sets the datapoint in manual operation mode in which the present value will be overwritten with a desired value manually entered by the user.

**Status Flags**

- In Alarm  
Datapoint is in alarm. Cause can be faults, Off-normal conditions, and life-safety alarm.
- Fault  
The datapoint or the physical input is not reliable, e.g. in case of sensor break (Open Loop).
- Overridden  
Present value is overridden manually
- Out of Service  
Physical input is decoupled from the datapoint, e.g. in case of manual override. The present value displayed is not the present value, which would be delivered by the physical input.
- 

NOTE: Multiple flag indications are possible.

**Fault**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Indicates the 'Fault' status of the datapoint.

When the 'Fault' status flag is enabled, the datapoint or the physical input is not reliable, e.g. in case of sensor break (Open Loop). See "Status Flag Indications" for details.

NOTE: Multiple flag indications may be possible.

**Alarm reporting of Faults**

The 'Fault' status of a point will generate an alarm if a notification class is selected.

Example: A 'To-Fault transition' will always enable the 'In Alarm' flag. Hence both, the 'In Alarm' and the 'Fault' status flags are enabled.

**In Alarm**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Indicates the 'Alarm' status of the datapoint.

Displays the alarm status of the datapoint, which can be caused by faults and Off-Normal conditions.

NOTE: Multiple flag indications may be possible.

Example: A 'To-Fault transition' will always enable the 'In Alarm' flag. Hence both, the 'In Alarm' and the 'Fault' status flags are enabled.

**Out Of Service**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Indicates the 'out of service' status of the datapoint.

The 'out of service' property allows decoupling the physical input or output from the datapoint.

For inputs the decoupling is done by manual override. For outputs this is done by checking the 'Out of Service' flag.

The 'out of service' property is suited to fix the physical input or output state, e.g. in case of checks.

In the following, the states of the 'out of service' flag/property of the various BACnet objects is listed:

AI, BI, MI

Out Of Service = unchecked:

Present value has not been overwritten

Out Of Service = checked:

Present value has been overwritten

Present value is decoupled from the physical input and will not track changes to the physical input.

AO, BO, MO

Out Of Service = checked:

Changes to the present value are decoupled from the physical output.

The present value property is still controlled by the prioritization mechanism (Priority Array, Relinquish Default)

AV, BV, MV

Out Of Service = checked:

Present value is prevented from being modified by the application.

The present value property is still controlled by the prioritization mechanism (Priority Array, Relinquish Default)

Pulse Converter

Out Of Service = unchecked:

Present value has not been overwritten

Out Of Service = checked:

Present value has been overwritten

Present value is decoupled from the Count property and will not track changes to the input.

**Overridden**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable									

Indicates the 'overridden' status of the datapoint.

If checked the datapoint is in manual operation mode and its value has been overwritten.

NOTES: When an AI datapoint is set into Manual mode and its value will be overwritten, the 'overridden' and 'out of service' flag will be set (see Status). The set out of service flag indicates that the datapoint is decoupled from the physical input (sensor) to prevent a sensor value from instantly overwriting the manual value in the next scan cycle.

When an AO datapoint is set into Manual mode, its current value will be overwritten by the manual value that has a higher priority (8). As long as no other process of higher priority writes to the analog output, the manual value is present. The overridden flag will be set (see Status).

If AO and BO datapoints are created with switches, the manual override control of the modules are reflected in the command priorities (level 1 = manual life safety).

Switching a point between Auto and Manu operating mode only causes an alarm if the value or state is in the Off-Normal range or status, and if the alarming is enabled.

**Alarming**

"Alarming" properties are the following:

- low limit enable
- high limit enable
- low limit
- high limit
- dead band
- alarm value
- state text
- suppress alarm
- alarm delay
- notification class
- notify type
- reporting events
- ackn. events
- to-off normal
- back-to normal
- to fault

**High Limit Enable**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

The High Limit Enable property defines if high limit alarms are generated on the BACnet bus. The following conditions must be true for the system to generate an alarm:

- High limit is exceeded and this condition present for at least the defined alarm delay (time)
- Transition events 'To-OffNormal' and 'To-Normal' are enabled
- Notification class (urgent, high or low) is allocated to this point
- Notify type is set to 'Alarm' (not 'Event')

If all of these conditions are true, then an alarm of event type 'To-Off-Normal' is set off.

The high limit can be predefined in CARE and changed in the NX component later.

NOTE: According to the BACnet standard, disabling the High Limit does only disable the reporting of the High Limit Alarm onto the BACnet bus. When the High Limit is exceeded, the datapoint will still be "in Alarm", and if a BACnet front-end is polling the alarms of a BACnet controller, also datapoints with High Limit disabled will be displayed on the BACnet front-end as being "in Alarm".

With the Excel Web II / Eagle controller it is possible to disable both High and Low Limit alarms at the same time, if the alarm delay time is set to 100,000 sec or longer.

**Low Limit Enable**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

The Low Limit Enable property defines the low limit for the creation of alarms of analog points. The following conditions must be true for the system to generate an alarm:

- The present value falls below the low limit and this condition represent for at least the defined alarm delay (time)
- Transition events 'To-OffNormal' and 'To-Normal' are enabled
- Notification class (urgent, high or low) is allocated to this point
- Notify type is set to 'Alarm' (not 'Event')

If all of these conditions are true, then an alarm of event type 'To-Off-Normal' is set off.

The Low Limit can be predefined in CARE and changed in the NX component later.

NOTE: According to the BACnet standard, disabling the Low Limit only disables the reporting of the Low Limit Alarm onto the BACnet bus. When the Low Limit is exceeded, the datapoint will still be "in Alarm", and if a BACnet front-end is polling the alarms of a BACnet controller, also datapoints with Low Limit disabled will be displayed on the BACnet front-end as being "in Alarm". With the Excel Web II / Eagle controller it is possible to disable both High and Low Limit alarms at the same time, if the alarm delay time is set to 100,000 sec or longer.

**State Text**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Multistate datapoints allow switching 256 states (stages) including the "off stage" of physical digital inputs or outputs. For each state, a state text can be created and assigned to the point in CARE. The state text is displayed on the NX component when the point switches the input or output to the corresponding state (stage).


Example: Multi-stage fan with state texts: stage 1, stage 2, stage 3, etc.

**Deadband**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	X								

Defines the value of the deadband in order to set off an alarm of event type 'To-Normal'. For this, the present value must, for at least the defined alarm delay (time), within the range:

Low limit plus deadband and high limit minus deadband



**Fig. 2. Deadband (1) of analog datapoints**

**Alarm Value**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Defines the alarm condition of a binary input or value point when an alarm should be reported in case of binary input changes. The alarm condition can be either the active state or the inactive state of the point e.g. 0 or 1, ON or OFF, Up or Down, etc.. If the present value is equal to this condition for at least the alarm delay time, then an OFF-Normal event is generated. In addition, an alarm delay can be entered.

**Suppress Alarm**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Enables/disables alarming for a datapoint.

**Alarm Delay**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

The alarm delay determines how long a 'To-Off-Normal' or a 'To-Normal' transition must exist before an alarm is generated. Entering an alarm delay time of 10 seconds means that the limit value must be exceeded for at least 10 seconds before this datapoint generates an alarm. If the limit value only lasts for 7 seconds, then no alarm occurs. The alarm handling for a datapoint can be completely disabled by setting the alarm delay time to a value of 100000 or higher.

**Notification Class**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Displays the notification class defined in CARE. The notification class enables alarming for the datapoint by selecting a notification class with a given priority. By default, the following notification classes with descending priority can be selected:

- Urgent
- High
- Low
- Journal

These default notification classes match the default notification classes of the BACnet client.

Each recipient assigned to a notification class will receive the datapoint alarm triggered by the selected notification. But, alarms will only be generated for the enabled transitions (To-Normal, To-OffNormal, and/or To-Fault) of a recipient. Each enabled transition will be propagated with the selected notification.

**Notify Type**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

The notify type can be defined and changed in CARE. In the NX component, the notify type (alarm type) is displayed only.

NOTE: For all notification classes, the notify type 'Alarm' must be used.

According to the BACnet Specification, events can be of the type 'alarm' or 'event'. On the BACnet client, alarms will be graphically indicated by blinking in the status line and shown in the alarm summary. Events will not be indicated in the status line and will be shown in the event summary.

**Reporting Events**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Defines which transition type (To-Off-Normal, Back To-Normal, and/or To Fault) will be reported and tracked by time stamping. Transitions will be saved in the alarm buffer and in the alarm list.

The timestamps can be seen under Transitions.

**Ackn. Events**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Shows whether a transition has been acknowledged or not. By default, each transition will be acknowledged by the controller and the Ackn. Property is checked.

**Last Transition**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Shows date of the last transition for the To-Off Normal, Back-To Normal and To Fault events.

**To-Off Normal**

Describes the To-Off Normal event state and transition type, respectively.

**Transition Events**

Whenever the event state of a datapoint changes, an alarm is generated by one of the following transition events:

**Back To-Normal**

The alarm is going to normal operating state, that is, the value of the datapoint returns under the high limit, or exceeds the low limit.

**To Off-Normal**

The alarm reaches off-normal state, that is, the datapoint value exceeds the high limit, or returns under the low limit.

**To Fault**

The alarm originates in a (physical) fault such as sensor break, etc.

Any alarm caused by a transition event is indicated by the enabled 'Alarm' status flag.

**Back-To Normal**

Describes the Back-To Normal event state and transition type, respectively.

**Transition Events**

Whenever the event state of a datapoint changes, an alarm is generated by one of the following transition events:

**Back To-Normal**

The alarm is going to normal operating state, that is, the value of the datapoint returns under the high limit, or exceeds the low limit.

**To Off-Normal**

The alarm reaches off-normal state, that is, the datapoint value exceeds the high limit, or returns under the low limit.

**To Fault**

The alarm originates in a (physical) fault such as sensor break, etc.

Any alarm caused by a transition event is indicated by the enabled 'Alarm' status flag.

**To Fault**

Describes the Fault event state and transition type, respectively.

**Transition Events**

Whenever the event state of a datapoint changes, an alarm is generated by one of the following transition events:

**Back To-Normal**

The alarm is going to normal operating state, that is, the value of the datapoint returns under the high limit, or exceeds the low limit.

**To Off-Normal**

The alarm reaches off-normal state, that is, the datapoint value exceeds the high limit, or returns under the low limit.

**To Fault**

The alarm originates in a (physical) fault such as sensor break, etc.

Any alarm caused by a transition event is indicated by the enabled 'Alarm' status flag.

**Other Properties**

"Other" properties are the following:

- object identifier
- reliability
- event state
- terminal PV
- out of service
- COV increment
- currently active priority
- EOH / EOv optimization flag
- datapoint is setpoint
- polarity
- resolution
- safety position
- direct reverse
- safety value
- sensor offset
- read access level
- write access level

**Object Identifier**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable									

The BACnet object ID is part of the internal BACnet addressing in every BACnet system (BACnet communication). The BACnet object ID is a unique ID within a BACnet device.

BACnet Object IDs must be provided by or to the project engineer/vendor who is responsible for the 3<sup>rd</sup> party BACnet device to be added to the CARE project, or who is responsible for integrating the Excel Web II / Eagle controller controller into a 3<sup>rd</sup> party BACnet system.

The BACnet object ID will be kept unique within a CARE project and is calculated within CARE by the following Standard BACnet formula:



BACnet object ID = BACnet object type x 2<sup>22</sup> + Object Instance number

The typical object addressing within a BACnet system is done by using the device ID and the Object ID.

**Reliability**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Shows whether the hardware assigned to the datapoint is in proper condition or not. Depending on the datapoint type, the following conditions may be displayed:

No Error Detected	Loop is in proper condition, that is, present value is reliable; that is, no other fault has been detected.
No Sensor	Sensor may be not connected
No Output	Hardware may be not connected
Unreliable Other	The controller has detected that the present value is unreliable, but none of the other conditions describe the nature of the problem. A generic fault other than those listed above has been detected, e.g., a Binary Input is not cycling as expected.

NOTE: For binary output datapoints, the reliability will work only if the service type of the corresponding NVo in CARE is set to 'acknowledged'.

**Event State**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

For any datapoint type, an application and/or product specific value range is defined in which the point is in the operating (event) state 'Normal'. If the point value has changed due to exceptional situations, the event state of a datapoint can be either 'Off-Normal' or 'Fault'.

The event states can be shortly described as follows:

**Normal**

Point is in normal operating state.

**Off-Normal**

Point value is out of normal range.

**Fault**

Point is prevented from proper operation. Point value can be in normal or out of normal range. Due to the maloperation of the point, the value is unreliable.

Causes for a fault can be, for example sensor and cable breaks. See "Status Flag indications for details.

**High Limit** (AI, AO, and AV datapoints only)

Point value has exceeded the high limit. Special case of the Off-Normal state of analog inputs, analog outputs, and analog value points (see also Alarm range properties in the table below).

**Low Limit** (AI, AO, and AV datapoints only)

Point value has dropped below the low limit. Special case of the Off-Normal state of analog inputs and outputs (see also Alarm range properties in the table below).

**Terminal PV**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Shows the name of the terminal to which the present value is mapped.

**Out Of Service**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Generates and indicates the 'out of service' status of the datapoint. The 'out of service' property allows decoupling the physical input or output from the datapoint.

For inputs the decoupling is done by manual override. For outputs this is done by checking the 'Out of Service' flag.

The 'out of service' property is suited to fix the physical input or output state, e.g. in case of checks. In the following, the states of the 'out of service' flag/property of the various BACnet objects is listed:

AI, BI, MI

Out Of Service = unchecked:

Present value has not been overwritten

Out Of Service = checked:

Present value has been overwritten

Present value is decoupled from the physical input and will not track changes to the physical input.

AO, BO, MO

Out Of Service = checked:

Changes to the present value are decoupled from the physical output.

The present value property is still controlled by the prioritization mechanism (Priority Array, Relinquish Default)

AV, BV, MV

Out Of Service = checked:

Present value is prevented from being modified by the application.

The present value property is still controlled by the prioritization mechanism (Priority Array, Relinquish Default)

Pulse Converter

Out Of Service = unchecked:

Present value has not been overwritten

Out Of Service = checked:

Present value has been overwritten

Present value is decoupled from the Count property and will not track changes to the input.

See also "In Alarm" and "Fault" sections.

**COV Increment**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

The change of value increment (COV increment) specifies the minimum change in present value that causes the controller sending the present value to recipients on the BACnet bus (e.g. NX component).

The COV increment is also used as the minimum change in the present value for value-based trending.

**Currently Active Priority**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

The value of the present value is controlled by a command prioritization mechanism which is based upon a fixed number of priorities that are assigned to command – issuing entities (BACnet tasks, control strategy, time program, and manual operator inputs). Each of these entities writes to the present value with its assigned priority level. The number of priorities is arranged in a priority list of descending priority.

Example:

	<b>Priority Level</b>	<b>Value</b>
1	Manual Life Safety	-
2		-
3		-
4		-
5	Critical Equipment Control	19,5 °C
6	Minimum On Off	
7		
8	Manual Operator	21,0 °C
9		-
10		-
11		-
12		-
13		-
14		-
15	Control Program	-
16		-
	Relinquish Default	20,0 °C

The priority list can include max. 16 values and will be continuously updated by written values caused by the command-issuing entities.

The value of the highest priority level is always written to the present value as long as the priority list is not empty. If the list is empty, the user-definable relinquish default value is written to the present value. For the example in the table, Critical Equipment Control has the highest priority and is written to the present value. As soon as the priorities 5 and 8 are relinquished e.g. via BACnet service, the relinquish default of 20, 0°C will be valid for the present value.

**EOV / EOY Optimization**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Defines whether the datapoint should be optimized or not, if the datapoint is used as setpoint for energy optimized heating or ventilation (EOH or EOY).

**Datapoint is Setpoint**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Displays whether the property **Setpoint** was set in CARE (true) or not (false).

**Polarity**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

The polarity indicates the relationship between the physical state of the input and the logical state represented by the present value. If the polarity is NORMAL, then the ACTIVE state of the present value is also the ACTIVE or ON state of the physical input. If the polarity is REVERSE, then the ACTIVE state of the present value is the INACTIVE or OFF state of the physical Input.

<b>Polarity</b>	<b>Present Value</b>	<b>Physical State of Input</b>	<b>Physical State of Device</b>
NORMAL	INACTIVE	OFF or INACTIVE	not running
NORMAL	ACTIVE	ON or ACTIVE	running
REVERSE	INACTIVE	ON or ACTIVE	not running
REVERSE	ACTIVE	OFF or INACTIVE	running

**Resolution**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows the resolution which defines the smallest recognizable change of the present value. The smaller the value the more precise a value change can be recognized.

**Safety Position**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	X								

In case of communication failure or application stop, the device is commanded to one of the following positions if the controller does not deliver a value (no response):

Analog Output:

- 0 %
  - 50 %
  - 100 %
- device is commanded to the selected percentage value

Binary Output:

- OFF (logical)
  - ON (logical)
- device is commanded to the selected logical state (name depends on state texts definition)
- ReGeneral in current position
- device is commanded to the last valid position

**NOTE:**

For analog outputs, the safety position is affected by the characteristic used for the controller modules. For particular characteristics there is no linear correlation between percentage value and voltage output:

<b>DP Type</b>	<b>Listbox number</b>	<b>Characteristic</b>	<b>Safety position (%)</b>	
			<b>0 50 100</b>	<b>in DP values</b>
				<b>in Volts</b>
AO	1..10	User defined		0 5 10
AO	9	0-100%=2-10V	-25 37.5 100	0 5 10

DP Type	Listbox number	Characteristic	Safety position (%)	
			0 50 100	
			in DP values	in Volts
AO	10	100-0%=2-10V	125 62.5 0	0 5 10
AO	12	LINEAR GRAPH	0 50 100	0 5 10
AO	24	0-10V=0-100%	0 50 100	0 5 10
AO	25	2-10V=0-100%	0 50 100	2 6 10
DO	--	DO on AO	OFF / ON	0 10
MOT	12	LINEAR GRAPH	0 50 100	0 5 10

NOTE: The user-defined characteristics 1 through 10 can be changed; in this context, characteristics 3, 4, 5, 6, 9, 10 are pre-defined by CARE (default characteristics) and characteristics 1 and 2 are not pre-defined. The default characteristics 3 through 6 are pressure input characteristics which should not be used for an analog output.

In general, for the user-defined characteristics 1 through 10, the safety positions 0%, 50%, 100% do always mean 0V, 5V, 10V; in this context the datapoint values for characteristics 9 and 10 are deviant.

**Direct/Reverse**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Allows turning the direction of a 0-10 V characteristic.

**Safety Value**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

In case of communication failure or application stop, the device is commanded to one of the following positions if the controller does not deliver a value (no response):

- Last Valid Value  
device is commanded to the last valid position
- Safety Value  
device is commanded to the value entered in Safety Value (CARE)

**Sensor Offset**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

The sensor offset applies only for analog input datapoints connected to panel bus or onboard IO's. It allows shifting the value.

The adjustable range is -100,000,000.0 through 100,000,000.0

It is entered in the engineering unit of the datapoints.  
If the datapoint is in fault state the sensor offset is not added to the datapoint.

**Read Access Level**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

The read access level can be defined and changed in CARE only. In the NX component, the read access level is displayed only.

The read access level assigned to a datapoint determines which user level can read values (properties) of that particular datapoint on the NX component.

A user who has a user level equal to or higher than the assigned read access level of the datapoint, will have this access right enabled in the NX component, all others will not.

**Write Access Level**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

The write access level can be defined and changed in CARE only. In the NX component, the write access level is displayed only.

The write access level assigned to a datapoint determines which user level can write values (properties) to that particular datapoint on the NX component.

A user who has a user level equal to or higher than the assigned write access level of the datapoint, will have this access right enabled in the NX component, all others will not.

**Command Priorities**

"Command" properties are the following:

- relinquish default

**Relinquish Default**

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Defines the value that will be written to the present value, if the priority list is empty which means that no other value is present in the priority list. The relinquish default value allows starting up a control system with a defined status/value.

The relinquish default value is predefined in the application in CARE and can be changed in the NX component.

**Priority Level**

The value of the present value is controlled by a command prioritization mechanism which is based upon a fixed number of priorities that are assigned to command – issuing entities (BACnet tasks, control strategy, time program, and manual operator inputs). Each of these entities writes to the present value with its assigned priority level. The number of priorities is arranged in a priority list of descending priority.

Example:

	Priority Level	Value
1	Manual Life Safety	-
2		-
3		-
4		-
5	Critical Equipment Control	19,5 °C

	Priority Level	Value
6	Minimum On Off	
7		
8	Manual Operator	21,0 °C
9		-
10		-
11		-
12		-
13		-
14		-
15	Control Program	-
16		-
	Relinquish Default	20,0 °C

The priority list can include max. 16 values and will be continuously updated by written values caused by the command-issuing entities.

The value of the highest priority level is always written to the present value as long as the priority list is not empty. If the list is empty, the user-definable relinquish default value is written to the present value.

For the example in the table, Critical Equipment Control has the highest priority and is written to the present value. As soon as the priorities 5 and 8 are relinquished e.g. via BACnet service, the relinquish default of 20,0 °C will be valid for the present value.

## Counters

"Counter" properties are the following:

- change of state count
- time of state count reset
- runtime (active time)
- time of last reset

### Change of State Count

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Displays the number of state changes of the binary datapoint

### Time of State Count Reset

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	-								

Shows the time of the last state counter reset for the binary datapoint.

### Runtime (Active Time)

Datapoint Type	AI	AO	AV	BI	BO	BV	MI	MO	MV
Editable	X								

Shows the runtime of the connected device. The runtime (active time) can be changed by reset.

The runtime can be reported as follows:

In CARE, use the IDT statement to read the 'Elapsed Active Time' property of a datapoint. Compare this value to a limit value and use an additional point to report an alarm.

---

**Time of Last Reset**

<b>Datapoint Type</b>	AI	AO	AV	BI	BO	BV	MI	MO	MV
<b>Editable</b>	-								

Shows the time of the last reset of a binary output or pulse converter datapoint.



# SCHEDULES AND CALENDARS

**Purpose** In the following, the viewing and editing of schedules and calendars are described.

There is no special import or export schedule procedure necessary. The schedule object is automatically synchronized with the controller schedule. The refresh button of the schedule does force a read from controller and the save action does force a write to the controller. Last update wins.


## Schedules

**Prerequisites** Discover schedules and calendars and add them to the station as described in the general procedure in the "Discover Objects of Controller and Add them to Station" section, or apply the import function as described in the "Import and Add Objects via EDE File Import" section.


- Procedure**
1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the controller.
  2. In the controller, expand the *Schedules* folder, and then double-click the schedule.

**RESULT:** On the right pane, by default the weekly schedule (Sun to Sat) is displayed graphically. The vertical time scale on the left shows the range of 12.00 AM to 12.00 AM.

**NOTE:** The sequence and the start day can be changed in the lexicons.



A schedule (when selected turns from green into blue color) is defined as event (block) starting with a switchpoint (event start) and ending with a switchpoint (event finish). The value of a switchpoint is called Event Output. The engineering units are not displayed and must be enabled separately as described in the "Set Schedule Properties" section. A switchpoint can be changed in the fields **Event Start**, **Event Finish**, and **Event Output** or graphically by moving the event start limiter and/or the finish limiter.



At the bottom of the pane, you will find further tabs with the following functions:

On the *Special Events* tab, you can define exceptions for every schedule (week program). Exceptions have higher priority than the week program and will overwrite the week program for a definable time period. Exceptions can be one of the following four time periods:

- Specific Date  
e.g. Christmas Eve or 5.5., the whole of May, or the whole year of 2004
- Date Range  
e.g. Summer holidays from 29.7-7.9.2004
- Recurring Event  
e.g. every last Friday of every month
- Calendar Reference  
A project-wide calendar provides dates, e.g. regional holidays and public/religious festivals or any other particular date. The time period can be a specific date, a date range or a recurring event.

The *Properties* tab shows miscellaneous general settings of the schedule such as default output, facet (engineering unit) etc.

The *Summary* tab shows in an interactive 5-month-based calendar the following switchpoint values in table format:

- timestamp
- output (value)
- source (which day of weekly schedule)

3. In the *Discovered* pane, the found datapoints are listed. Select the datapoints you want to add to the station. Multi-selection using the SHIFT or STRG key is possible.

4. Click **Add** button.

---

## Edit Weekly Program

The edition of a weekly program may include the following tasks.


- Create switchpoints
- Change switchpoints, e.g. event start and/or finish time, and or output value
- Copy days
- Clear days
- Clear week
- Delete event
- Set switch block as all day event
- Apply switch block to workdays (Monday through Friday)

---

## Create Switchpoint

**Procedure**

1. Select the *Weekly* tab at the bottom of the right pane.
2. Create a blank area where you want to create a switchpoint as described in the "Clear day" and "Clear Week" sections.
3. Add new switchpoint(s) graphically as follows:
  - a. click with the mouse button at the event start time.
  - b. With pressed mouse button move the cursor upwards or downwards to the event finish time.
  - c. At the event finish time, release the mouse button.



4. Click **Save** button.

**Change Switchpoint**


For a switchpoint any of the following can be changed:

- event start and/or finish time
- output value

**Procedure**

1. Select the *Weekly* tab at the bottom of the right pane.
2. Click into the switch block.

**RESULT:** The switch block is highlighted in blue. In the Event Start and Event Finish fields the start and end times are displayed. The Event Output field shows the value.




3. Do any of the following:


- a. to change the event start or event finish time, click the hours and minutes digits respectively in **Event Start** or **Event Finish**, and then adjust the time by clicking the upwards or downwards button.



- b. or, in the graphic view, hover over the start or finish time until the hand cursor switches to a 2-arrow cursor. Then click with the mouse button and with pressed mouse button move the cursor upwards or downwards to the desired time. At the desired time, release the mouse button.



- c. To change the output value, click in the **Event Output** field, and enter the value. If desired, click **null** check box. The null value removes the current value entry of the switch point from the priority array. Then the next lower value in the priority array becomes the present value.




- 4. Click **Save** button.


**Copy Day**

**Procedure**

1. Select the *Weekly* tab at the bottom of the right pane.
2. Right-click into a switch block of the source day you want to copy.
3. In the context menu, click **Copy Day**.



4. Right-click into a switch block of the target day.



4. In the context menu, click **Paste Day**.


RESULT: The day with all switch blocks is copied to the target day.

5. Click **Save** button.

### Clear Day

**Procedure**

1. Select the *Weekly* tab at the bottom of the right pane.
2. Right-click into a switch block of the day you want to clear.



3. In the context menu, click **Clear Day**.

RESULT: All switch blocks are removed and the default output value defined on the *Properties* tab is assigned to the day.

4. If desired, add new switch blocks graphically as follows:
  - a. click with the mouse button at the event start time.
  - b. With pressed mouse button move the cursor upwards or downwards to the event finish time.
  - c. At the event finish time, release the mouse button.
5. Click **Save** button.

### Clear Week


This function is performed in the same way as clearing a day. Please refer to the "Clear Day" section. Instead, use the **Clear Week** command in the context menu.

RESULT: All switch blocks are removed and the default output value defined on the *Properties* tab is assigned to the each day of the week.

### Delete Event

**Procedure**

1. Select the *Weekly* tab at the bottom of the right pane.
2. Right-click the switch block you want to delete.




3. In the context menu, click **Delete Event**.

RESULT: The switch block is deleted. The default output value is set for the empty switch block.

### Set Switch Block as All Day Event

- Procedure**
1. Select the *Weekly* tab at the bottom of the right pane.
  2. Right-click the switch block.




3. In the context menu, click **All Day Event**.

RESULT: All existing switch blocks are merged into one switch block. The default output value is set for the complete switch block.

### Apply Switch Block to Workdays (Monday through Friday)

- Procedure**
1. Select the *Weekly* tab at the bottom of the right pane.
  2. Right-click the switch block.



3. In the context menu, click **Apply M-F**.

**RESULT:** The selected switch block will be applied to all workdays of the week.


## Create Special Events

On the *Special Events* tab, you can define exceptions for every schedule (week program). Exceptions have higher priority than the week program and will overwrite the week program for a definable time period. Exceptions can be one of the following four time periods:


- Specific Date  
e.g. Christmas Eve or 5.5., the whole of May, or the whole year of 2004
- Date Range  
e.g. Summer holidays from 29.7-7.9.2004
- Recurring Event  
e.g. every last Friday of every month
- Custom  
allows any kind of combination
- Calendar Reference  
A project-wide calendar provides dates, e.g. regional holidays and public/religious festivals or any other particular date. The time period can be a specific date, a date range or a recurring event.

- Procedure**
1. Select the *Special Events* tab at the bottom of the right pane.

**RESULT:** On the top, a calendar starting with the current month and the following 5 months is displayed.

2. Click the **Add** command .

RESULT: The *Add* dialog box displays.




3. In the **Name** field, enter a name for the special event.

4. From the **Type** drop-down list box, select the type under:


- Date  
e.g. Christmas Eve or 5.5., the whole of May, or the whole year of 2014

a. In the fields below, set the day by selecting the weekday, date, month and year.



- Date Range  
e.g. Summer holidays from 29.7-7.9.2014

b. In the fields below, set data range by selecting the weekday, month and year.





- Recurring Event  
e.g. every Friday of every week, of every month

c. In the fields below, set dates by selecting the weekday, week, and month.

- Custom  
allows any kind of combination

d. In the fields below, set dates by selecting the corresponding options.

- Calendar Reference  
A project-wide calendar provides dates, e.g. regional holidays and public/religious festivals or any other particular date. The time period can be a specific date, a date range or a recurring event.

e. In the list, select the calendar.

In the following, a special event of type "date range" is created as an example.

5. Click **OK**.

RESULT: The special event is added to the list.

Name	Summary
Event	Date Range: 27 2017 - 31 2017
DailySchedule	Reference: bac:device:11;analogInput:0[schedule]

6. On the right, add switch points for the special event as described in the "Create Switchpoint" section.

3:00 AM Unscheduled

6:00 AM 12.0

9:00 AM

12:00 PM

3:00 PM

6:00 PM


9:00 PM

Event Start

Event Finish

Event Output  null

RESULT: The special event is indicated in green in the calendar.




7. Click the **Save** button

### Set Schedule Properties


The *Properties* tab allows editing of miscellaneous general settings of the schedule such as default output, facet (engineering unit) etc.

**Procedure** 1. Select the *Properties* tab at the bottom of the right pane.


RESULT: On the top, a calendar starting with the current month and the following 5 months is displayed.




2. To change the default output value, enter the value in the *Default Output* field and click **Save** button.
3. To enable the display of the engineering units in the schedule, do the following:
  - a. click the arrow at the clock icon
  - b. click desired units in the pop-up window.
  - c. click arrow
  - d. In the *Config Facets* dialog box, click browse button in the units row.




- e. Select engineering unit in the right drop-down listbox.





f. Click **OK**.

RESULT: The facet is changed.



4. To clean up special events, select `True` from the **Cleanup Special Events** drop-down listbox. This removes a special event after it has expired.

### View Schedule Summary

The *Properties* tab shows miscellaneous general settings of the schedule such as default output, facet (engineering unit) etc.

The *Summary* tab shows in an interactive 5-month-based calendar the following switchpoint values in table format:

- timestamp
- output (value)
- source (which day of weekly schedule)

**Procedure** 1. Select the *Summary* tab at the bottom of the right pane.

RESULT: On the top, a calendar starting with the current month and the following 5 months is displayed.

Navigation: ◀ Prev Page ◀ Prev Month Today Next Month ▶ Next Page ▶

Feb 2017							Mar 2017							Apr 2017							May 2017							Jun 2017						
s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s
			1	2	3	4				1	2	3	4							1		1	2	3	4	5	6					1	2	3
5	6	7	8	9	10	11	5	6	7	8	9	10	11	2	3	4	5	6	7	8	7	8	9	10	11	12	13	4	5	6	7	8	9	10
12	13	14	15	16	17	18	12	13	14	15	16	17	18	9	10	11	12	13	14	15	14	15	16	17	18	19	20	11	12	13	14	15	16	17
19	20	21	22	23	24	25	19	20	21	22	23	24	25	16	17	18	19	20	21	22	21	22	23	24	25	26	27	18	19	20	21	22	23	24
26	27	28					26	27	28	29	30	31	23	24	25	26	27	28	29	28	29	30	31				25	26	27	28	29	30		
													30																					

Timestamp	Output	Source
02-Feb-17 12:00 AM CET	14.0 [ok]	Week: thursday
02-Feb-17 8:00 AM CET	16.0 [ok]	Week: thursday

Weekly Schedule Special Events Properties Summary

## Calendar References

Schedules can be referenced to calendars in CARE. When deleting a calendar in *ARENA NX / COACH NX*, the deleted calendar will be uploaded from the controller the next time you click on the corresponding referenced schedule in *ARENA NX / COACH NX*.

Navigation: ◀ Prev Page ◀ Prev Month Today Next Month ▶ Next Page ▶

Feb 2017							Mar 2017							Apr 2017							May 2017							Jun 2017						
s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s	s	m	t	w	t	f	s
			1	2	3	4				1	2	3	4							1		1	2	3	4	5	6					1	2	3
5	6	7	8	9	10	11	5	6	7	8	9	10	11	2	3	4	5	6	7	8	7	8	9	10	11	12	13	4	5	6	7	8	9	10
12	13	14	15	16	17	18	12	13	14	15	16	17	18	9	10	11	12	13	14	15	14	15	16	17	18	19	20	11	12	13	14	15	16	17
19	20	21	22	23	24	25	19	20	21	22	23	24	25	16	17	18	19	20	21	22	21	22	23	24	25	26	27	18	19	20	21	22	23	24
26	27	28					26	27	28	29	30	31	23	24	25	26	27	28	29	28	29	30	31				25	26	27	28	29	30		
													30																					

Timestamp	Output	Source
02-Feb-17 12:00 AM CET	14.0 [ok]	Week: thursday
02-Feb-17 8:00 AM CET	16.0 [ok]	Week: thursday

Weekly Schedule Special Events Properties Summary

1. To view the switchpoint values of a day, click the date in the calendar.

RESULT: In the area below, the following values are displayed in the table columns.

- timestamp
- output (value)
- source (which day of weekly schedule)


## ALARMS

### Prerequisites

For getting and viewing alarms, the following steps must be performed:

1. The BACnet notification classes must be imported by the EDE file process or manually via discovery. Once imported, they are located in the *Alarms* folder of the controller.
2. The Niagara alarm classes must be manually connected to the alarm console recipient.
3. The Niagara Alarm classes must be manually assigned to the imported BACnet notification classes.
4. Alarm extensions must be assigned to datapoints of which alarms should be shown

**NOTE:** ARENA NX / COACH NX will be automatically defined as alarm console recipient for the controller.




## Import / Discover BACnet Notification Classes

Please refer to the "Discover Objects of Controller and Add them to Station" and "Add Objects to Station via EDE File Import " sections.

## Connect Niagara Alarm Classes to Alarm Console Recipient


### Procedure

1. In the *Nav side bar* on the left, expand the *Station* folder and browse to the *AlarmService* folder.
2. Right-click the *AlarmService* folder, click **Views**, and then click **Wire Sheet** in the context menu.




3. In the *Palette* tab at the bottom, select **alarm** from the drop-down listbox, and then drag&drop **AlarmClass** to the wiresheet.


RESULT: The *Name* dialog box is displayed.



4. Change the name of the alarm class, e.g. 'High`.




RESULT: The alarm class is added to the wiresheet.




5. Add all required alarm classes to the wiresheet in the same way.

6. From the *Palette* tab, drag&drop the console recipient to the wiresheet.



7. To link an alarm class to the alarm recipient, click on the yellow-green **Alarm** bar of the alarm class icon, and with mouse button pressed draw a line to the console recipient's green **Route Alarm** bar. When the cursor turns to arrow shape, release the mouse button.



8. Repeat step 7 for connecting the remaining alarm classes.

---

## Assign Niagara Alarm Classes to BACnet Notification Classes


---

### Procedure


1. In the *Nav* side bar on the left, expand the *Station* folder and browse to the *Alarms* folder.
2. Open the *Alarms* folder.

RESULT: In the *Nav* side bar, the BACnet notification classes are displayed.





3. Double-click the notification class.
4. On the *Property Sheet* on the right, assign the corresponding Niagara alarm class from the **Niagara Alarm Class** drop-down listbox.




5. Click the **Save** button at the bottom.
6. Repeat steps 4 and 5 for all notification class - alarm class assignments.


## Assign Alarm Extension to Datapoint

**Purpose** This alarming function can be used if alarms are not generated by the controller by default. Using this function, alarming will then be handled by the ARENA NX supervisor.


- Procedure**
1. In the *Palette* tab, expand the *Extensions* folder.




2. Drag&drop the desired alarm extension to the datapoint in the *Points* folder.




3. Change the name of the extension in the Name dialog box if desired, and then click the OK button.



RESULT: The alarm extension is assigned to the datapoint.




4. Open the alarm extension and define the settings for the Fault and Offnormal algorithms according to the configured datapoint settings. E.g. if 'Low Limit Enable' or 'High Limit Enable' is configured in the datapoint properties, these options must also be configured in the assigned extension.



## View Alarms

- Procedure** 1. To view alarms, double-click the *Alarm* folder in the *Nav* side bar.


RESULT: The current alarms are displayed on the right pane.



# TRENDING


NOTE: In ARENA NX / COACH NX when using an OWS profile, you cannot create trend objects, but only view already existing trends. When using an AWS profile these tasks are possible.

1. In the *Nav side bar*, expand the station and navigate to the controller in the *History* folder.
2. Open the controller, and click on the *Trend Logs* folder.




3. On the right, click the **Discover** button.

RESULT: The discovered trended datapoints are displayed on the *Discovered* pane.




4. Select the trend objects, you want to add to the database, and then click the **Add** button at the bottom.

RESULT: The *Add* dialog box displays.



5. Click the **OK** button at the bottom.

RESULT: The trend objects are added to the database as indicated by the display on the *Database* pane and in the *Trend Logs* folder in the Nav side bar.



4. To view the graphical trend data of datapoint, double-click the item in the tree.


RESULT: On the right pane, the trend data of the datapoint is shown.

## RESET CONTROLLER CONFIGURATION

If supported, the Reset Config feature deletes the following items in the controller:

- datapoints,
- folder structures
- calendars and schedules
- notification classes
- alarm classes  
(applies only to alarm classes not used by other controllers)

1. In the *Nav side bar*, right-click the controller, click **Actions**, and then click **Reset Config**.



## IRM CONTROLLER PARAMETERS

Parameters of IRM controllers can be accessed by using an Eagle controller as MSTP gateway. The parameters will be loaded via a parameter set, which is a CSV file provided with the CentralLine NX installation by default.


### Load Parameters

#### Prerequisite Steps

1. Connect the IRM controller to the EAGLE controller via their MSTP interface. Please refer to the corresponding product data and mounting instructions.
2. In CARE, create the EAGLE controller and configure it as MSTP gateway.
3. Create a "dummy" plant including e.g. 1 analog value datapoint.
4. Download the application and the controller settings into the EAGLE controller (see CARE User Guide EN2Z-0937GE51).
5. Configure the IRM controller by using the RoomUp App (see IRM Application Guide EN2Z-1015GE51).

#### Procedure


1. In COACH NX / ARENA NX, discover the EAGLE and IRM controllers.



- In the *Palette* tab at the bottom, select **honBACnetUtilities** from the drop-down listbox, then open *Configuration*, and then drag&drop the parameters item, in this case, **BACnetDeviceParameters** to the IRM controller.


NOTE: Multiple parameter items can be added to the IRM controller.

RESULT: The *Name* dialog box is displayed.




- Change the name if desired, and then click **OK**.

RESULT: The parameters item is added to the controller as indicated in the tree.




- Double-click on the parameters item.


RESULT: On the Property Sheet on the right, the CSV file can be selected from the **Parameter Set** drop-down listbox.




NOTE: Parameter sets are listed according to the Vendor ID and the Model Name of the BACnet device. One parameter set can fit to multiple model names. Only matching parameter sets will be selectable. If no matching parameter set is found, a message is displayed.




The action **Load Set List** will refresh the list of available parameter sets.



5. Select the CSV file, in this case, IRM H\_0002.csv.



RESULT: The parameters are displayed according to the IRM RoomUp structure. The parameters can be further grouped in subfolders






## Change Parameters


The parameters have value and status, and they are only polled when visible. Values can be changed directly in the field or by using the **Set** action. Based on the Facet setting = default, the default value can be written using the **Set Default** action.

The status changes when read or write faults occur.


- Procedure**
1. To edit parameters, expand the corresponding tree item.




2. Change the value directly in the field, and then click the **Save** button at the bottom.




**RESULT:** The value is updated.




3. Alternatively, you can change parameters by using the **Set** action.




4. To do so, right-click on the parameter setting which is indicated by the icon , select **Actions**, and then click **Set** in the context menu.


RESULT: The *Set* dialog box is displayed.



5. Change the value, and then click **OK**.



RESULT: The value is updated.




---

## Binding of Parameters

---

Parameters can be bound using standard Niagara Widget functions such as:

- Label binding
- PX file usage
- Palette items bindings (animated graphics, boolean types, etc.)
- Field editor usage
- Actions binding

Please refer to the basic Niagara documentation for detailed information on these techniques.

---

## WEBSTART BROWSER USAGE

---

**NOTE:** When using the ORACLE Webstart browser on a PC or notebook the display of the pages may take a long time since the browser function is based on JAVA applets which are not used in mobile applications.

Further details about WebStart are described in the document docWebStart.pdf which is located in the docs folder of the ARENA NX / COACH NX installation folder.

---

## “HOW TO” INSTRUCTIONS

---

For the BACnet Utilities driver, the following additional feature is available

- Emergency Actions Always Hidden

The corresponding detailed information is included in “How to” Instructions which can be downloaded from the CentralLine FAQ database at:

<https://clfaq.ge51.honeywell.de/>

## INDEX

**A**

- Access levels
  - view, 53
- Ackn. events
  - datapoint property description, 63
- Active priority
  - datapoint property description, 67
- Add
  - controller objects to station, 29
  - controller to station, 27
  - objects to station, 31, 35
- Alarm
  - datapoint, 86
- Alarm console recipient
  - connect Niagara alarm class, 86
- Alarm delay
  - datapoint property description, 62
- Alarm value enable
  - datapoint property description, 62
- Alarming
  - High limit enable, 60
- Alarming
  - datapoint property descriptions, 60
  - enable/disable, 47
  - procedures), 46
  - set off-normal conditions, 46
- Alarms, 86
- Alarms
  - alarm console recipient, 86
- Alarms
  - Niagara alarm classes, 88
- Alarms
  - BACnet notification classes, 88
- Alarms
  - extensions, 90
- All day event
  - set, 78
- Analog input
  - auto mode, 50
  - manual mode, 50
  - manual override, 50
  - set from override into Auto mode, 50
  - set into manual mode, 50
- Apply
  - switch block to workdays, 78
- Auto mode
  - analog input, 50
  - datapoint, 51
  - set analog input into, 50
  - set datapoint into, 51

**B**

- Back To-Normal
  - transition events, 63, 64
- BACnet ID
  - datapoint property description, 64
- BACnet network
  - create, 22
- BACnet notification classes
  - assign to Niagara alarm classes, 88
  - discover, 86
  - import, 86

- Binding
  - parameters, 98
- BNA (CLIF)
  - OS numbers, 7
  - system requirements, 7
- Browser usage
  - ORACLE webstart, 99

**C**

- Calendar references, 85
- Calendars, 73
- C-Bus
  - licenses, 7
  - point handling, 7
- Change
  - parameters, 97
  - switchpoint, 75
- Change
  - COV increment, 53
  - individual datapoint property, 53
  - present value, 45, 49, 50
  - relinquish default, 48, 49
  - safety position, 53
  - sensor offset, 53
- Change of state count
  - datapoint property description, 71
- Change of value
  - datapoint property description, 66
- Change of value (COV), 66
- Clear
  - day, 77
  - week, 77
- Command priorities
  - datapoint property description, 70
- Command properties
  - view, 48
- Compatibility matrix
  - system requirements, 7
- Connect
  - station, 20
- Controller
  - datapoint property description, 56
  - reset configuration, 94
- Controller
  - add objects to station, 29
  - add to station, 27
  - discover objects, 30, 31
  - EDE file import, 30, 35
- Controllers
  - OS numbers, 7
- Copy
  - day, 76
- Copy
  - station, 18
- Counters
  - datapoint property description, 71
- Counters
  - reset, 54
  - view, 54
- COV
  - see Change of value, 66
- COV increment
  - change, 53
- Create

- special events, 79
- switchpoint, 75
- Create
  - BACnet network, 22
  - network, 22
  - station, 16

## D

- Datapoint
  - alarm, 86
- Datapoint
  - auto mode, 51
  - emergency auto mode, 53
  - emergency override mode, 52
  - event states (alarm behavior), 65
  - manual mode, 50
  - manual override, 50
  - reliability, 65
  - set from override into Auto mode, 51
  - set into emergency auto, 53
  - set into emergency override, 52
  - set into manual mode, 50
  - transition events, 63, 64
- datapoint is setpoint
  - datapoint property description, 67
- Datapoint properties
  - alarming procedures, 46
  - edit, 40, 44
  - edit procedures, 42
  - general, 44
  - general edit procedure, 43
  - view, 40
  - view status flags, 44
- Datapoint property
  - change, 53
  - individual, 53
- Datapoint property description
  - ackn events, 63
  - active priority, 67
  - Alarm delay, 62
  - alarm value enable, 62
  - BACnet object ID, 64
  - change of state count, 71
  - Change of value, 66
  - controller, 56
  - counters, 71
  - datapoint is setpoint, 67
  - deadband, 61
  - description, 57
  - direct/reverse, 69
  - EOV / EOH optimization, 67
  - event state, 65
  - fault, 58
  - High limit enable, 60
  - in alarm, 58
  - increment, 66
  - last transition, 63
  - low limit enable, 60
  - name, 57
  - notification class, 62
  - notify type, 62
  - out of service, 58, 66
  - overridden, 59
  - polarity, 68
  - present value, 57
  - priority level, 67, 70
  - read access level, 70
  - reliability, 65
  - relinquish default, 70
  - reporting events, 63
  - resolution, 68
  - runtime (active time), 71
  - safety position, 68
  - safety value, 69
  - sensor offset, 69
  - state text, 61
  - status, 57
  - status flags, 58
  - suppress alarm, 62
  - terminal PV, 66
  - time of last reset, 72
  - time of state count reset, 71
  - transition events, 63
  - type, 57
  - write access level, 70
- Datapoint property descriptions
  - alarming, 60
  - command priorities, 70
  - general, 56
  - other, 64
  - summary, 55
- Datapoint value
  - set, 49
- Day
  - clear, 77
  - copy, 76
  - paste, 76
- Deadband, 61
  - datapoint property description, 61
- Delete
  - event, 77
- Description
  - datapoint property description, 57
- Direct reverse
  - datapoint property description, 69
- Discover
  - BACnet notification classes, 86
  - objects, 30, 31

## E

- EDE file
  - import, 30, 35
- Edit
  - weekly program, 74
- Edit
  - datapoint properties, 40, 44
  - datapoint properties (alarming procedures), 46
  - datapoint properties (general procedure), 43
  - datapoint properties (procedures), 42
  - general datapoint properties, 44
- Emergency auto
  - set datapoint into, 53
- Emergency auto mode
  - datapoint, 53
- Emergency override
  - set datapoint into, 52
- Emergency override mode
  - datapoint, 52
- Enable
  - HonBACnetService, 26
- EOV / EHV optimization
  - datapoint property description, 67
- Event
  - delete, 77
- Event state
  - datapoint property description, 65
  - view, 53
- Event states

datapoint alarm behavior, 65

Extensions  
alarm, 90

## F

Fault  
datapoint property description, 58  
Fault  
status flag, 58

## H

High  
notification class, 62  
High limit enable  
alarming, 60  
datapoint property description, 60  
Hon datapoint view, 40  
HonBACnet point properties view, 40  
HonBACnetService  
enable, 26

## I

Import  
BACnet notification classes, 86  
EDE file, 30, 35  
In alarm  
datapoint property description, 58  
status flag, 58  
Increment  
datapoint property description, 66  
Installation, 7  
Intrinsic reporting  
enable/disable, 47  
IRM controller  
binding parameters, 98  
change parameters, 97  
load parameters, 94  
parameters, 94

## L

Last transition  
datapoint property description, 63  
Licenses  
C-Bus, 7  
point handling, 7  
Load  
parameters, 94  
Low  
notification class, 62  
Low limit enable  
datapoint property description, 60

## M

Manual mode  
analog input, 50  
datapoint, 50  
set analog input into, 50  
set datapoint into, 50  
Manual override  
analog input, 50  
datapoint, 50

## N

Name  
datapoint property description, 57  
Network  
create, 22  
Niagara  
system requirements, 7  
Niagara alarm class  
connect to console recipient, 86  
Niagara alarm classes  
assign to BACnet notification classes, 88  
No error detected  
reliability, 65  
No output  
reliability, 65  
No sensor  
reliability, 65  
Notification class  
datapoint property description, 62  
high, 62  
low, 62  
urgent, 62  
Notify type  
datapoint property description, 62

## O

Off-normal conditions  
set, 46  
Open  
platform, 9  
Open loop  
reliability, 65  
Operating mode  
set, 50  
ORACLE Webstart, 99  
OS numbers  
BNA (CLIF), 7  
controllers, 7  
Out of service  
datapoint property description, 58, 66  
Overridden  
datapoint property description, 59

## P

Parameters  
binding, 98  
change, 97  
IRM controller, 94  
load, 94  
Paste  
day, 76  
Platform  
open, 9  
Point handling  
C-Bus, 7  
licenses, 7  
Polarity  
datapoint property description, 68  
Present value  
datapoint property description, 57  
Present value  
change, 45, 49, 50  
Priority array, 67  
Priority level  
datapoint property description, 67, 70

**R**

- Read access level
  - datapoint property description, 70
- Reliability
  - datapoint property description, 65
- Reliability
  - datapoint, 65
  - no error detected, 65
  - no output, 65
  - no sensor, 65
  - open loop, 65
  - unreliable other, 65
  - view, 53
- Relinquish default, 70
- Relinquish default
  - datapoint property description, 70
- Relinquish default
  - change, 48, 49
- Reporting events
  - datapoint property description, 63
- Reset
  - controller configuration, 94
- Reset
  - counters, 54
- Resolution
  - datapoint property description, 68
- Runtime (active time)
  - datapoint property description, 71

**S**

- Safety position
  - datapoint property description, 68
- Safety position
  - change, 53
- Safety value
  - datapoint property description, 69
- Schedule
  - view summary, 84
- Schedule properties
  - set, 82
- Schedules, 73
  - apply switch block to workdays, 78
  - calendar references, 85
  - change switchpoint, 75
  - clear day, 77
  - clear week, 77
  - copy day, 76
  - create switchpoint, 75
  - delete event, 77
  - edit weekly program, 74
  - paste day, 76
  - properties, 82
  - set all day event, 78
  - summary, 84
- Sensor offset
  - datapoint property description, 69
- Sensor offset
  - change, 53
- Set
  - all day event, 78
  - datapoint value, 49
  - schedule properties, 82
- Set
  - operating mode, 50
- Set
  - operating mode, 50
- Special events
  - create, 79

**Start**

- CentraLine NX, 7
- station, 20
- State text
  - datapoint property description, 61
- Station
  - add controller, 27
  - add controller objects, 29
  - add objects, 31, 35
  - connect, 20
  - copy, 18
  - create, 16
  - start, 20
- Status
  - datapoint property description, 57
- Status flag
  - fault, 58
  - in alarm, 58
- Status flags
  - datapoint property description, 58
- Summary
  - view, 84
- Suppress alarm
  - datapoint property description, 62
- Switchpoint
  - change, 75
  - create, 75
- System requirements
  - BNA (CLIF), 7
  - Niagara, 7
  - ompatibility matrix, 7

**T**

- Terminal PV
  - datapoint property description, 66
- Time of last reset
  - datapoint property description, 72
- Time of state count reset
  - datapoint property description, 71
- To Fault
  - transition events, 63, 64
- To-Offnormal
  - transition events, 63, 64
- Transition events
  - Back To-Normal, 63, 64
  - datapoint, 63, 64
  - datapoint property description, 63
  - To Fault, 63, 64
  - To-Offnormal, 63, 64
- Trending, 92
- Type
  - datapoint property description, 57

**U**

- Unreliable other
  - reliability, 65
- Urgent
  - notification class, 62

**V**

- View
  - access levels, 53
  - command properties, 48
  - counters, 54
  - datapoint properties, 40
  - event state, 53
  - general datapoint properties, 44

- reliability, 53
- status flags, 44
- summary, 84

**Views**

- Hon datapoint view, 40
- HonBACnet point properties, 40

**W****Week**

- clear, 77

**Weekly program**

- apply switch block to workdays, 78

- change switchpoint, 75

- clear day, 77

- clear week, 77

- copy day, 76

- create switchpoint, 75

- delete event, 77

- edit, 74

- paste day, 76

- set all day event, 78

**Workdays**

- apply switch block, 78

**Write access level**

- datapoint property description, 70





Manufactured for and on behalf of the Environmental and Energy Solutions Division of Honeywell Technologies Sàrl, Rolle, Z.A. La Pièce 16, Switzerland by its Authorized Representative:

CentraLine  
Honeywell GmbH  
Böblinger Strasse 17  
71101 Schönaich, Germany  
Phone +49 (0) 7031 637 845  
Fax +49 (0) 7031 637 740  
info@centraline.com  
www.centraline.com

Subject to change without notice  
EN2Z-1020GE51 R0418

