

- D Montageanweisung
- F Instructions d'installation
- I Istruzioni di montaggio
- NL Installatievoorschrift
- DK Installasjonsinstruktus
- N Installationsinstruktioner
- FIN Asennusohje
- S Installation instruktioner
- E Instrucciones de montaje

M7061

INSTALLATION INSTRUCTIONS

1

M7061E1012 / M7061E1020

V5004TY A, B

V5421B A, B, F

VBG2, VBG3 A, B

DRxxGxLA A, B

M7061
INST. INSTRUCTIONS
(MU1B-0243GE51)

2

V5004TY **V5421B** **E**

INST. INSTR. (MU1B-0655GE51) INST. INSTR. (EN1B-1007GE51)

VBG2, -3 **DRG** **C**

MU1B-0570GE51 MU1B-0584GE51 MU1B-0367GE51

<https://products.ecc.emea.honeywell.com/europe>

3

EXAMPLE → ⑦

V5004TY = 90%, PL = 24°, lever = -4.4 cm

4

0% 50%

V5004TY, V5421B, VBG2, -3

50% 0%

5

V5004TY, V5421B

V5004TY, V5421B

6

K=1

K=3

K=5

K=7

K=9

90°

45°

0°

0% 50% 100%

Y

7

V5004TY	100%	90%	80%	70%	60%	50%	40%	30%
PL	15°	24°	33°	42°	51°	60°
cm	-6.0	-4.4	-3.1	-1.9	-1.0	0.0	1.0	+1.9

V5421B	90°	80°	70°	60°	50°	45°	30°	20°
PL	15°	25°	35°	45°	55°	60°
cm	-6.0	-4.2	-2.8	-1.6	-0.5	0.0	+1.6	+2.8

8

B

A

cm

C

9

1 2 3 4 5

24VAC

Y

0...10VDC
(2...10VDC)

0% :

100% :

2 3 4 2 3 4

Y

Y