






D Montageanweisung
F Instructions d'installation

LFV

Duct Temperature Transmitter

MOUNTING INSTRUCTIONS





Automation and Control Solutions

Honeywell GmbH
Böblinger Strasse 17
71101 Schönaich, Germany
Phone +49 (0) 7031 637 01
Fax +49 (0) 7031 637 740
<http://ecc.emea.honeywell.com>